



Programmable controller Installation manual



CONTENTS

1	Introduction	4
1.1	General description	4
1.1.1	Specifications:	5
1.1.2	Main functions of hardware:	6
1.2	Models and Features	6
2	Mechanical installation	7
2.1	Mechanical dimensions	9
3	Electrical connections	10
3.1	General warnings	10
3.1.1	Power supply - High voltage inputs (relay)	10
3.1.2	TRIAC	10
3.1.3	Analogue Inputs-Probes	10
3.1.4	Serial connections	11
3.2	Wiring diagrams	12
3.2.1	Example of low voltage input/output connection	17
3.2.2	Example of NTC/DI input connection	18
3.2.2.1	Example of AO1 / AO2 connection	18
3.2.2.2	Example of AO3 - AO4/A05 connection	18
3.2.2.3	Example of DO5 connection	19
3.2.3	Example of connection of high voltage outputs	19
3.3	Network connection examples	20
3.3.1	Example of Smart SMP→ SE6xx connection	20
3.3.2	Example of SMD/SMC → SE6xx connection	20
3.3.3	Example of SMC – SKP 10 connection	20
3.3.4	SKW22(L), wall-mounted LCD terminal	21
3.3.5	SKW22(L), panel-mounted LCD terminal	22
3.3.6	Example of SMC – SE6xx – SKP 10 – LCD terminal connection	22
4	Technical Data	23
4.1	General specifications	23
4.2	I/O features	23
4.3	Mechanical specifications	25
4.4	Serials	25
4.5	Transformer	25
4.6	Mechanical dimensions	25
4.7	Permitted use	26
4.8	Improper Use	26
4.9	Disclaimer	26
5	User Interface (folder PAr/UI)	27
5.1	Keys	27
5.1.1	Description of keys – combined action	27
5.2	LEDs and Display	28
5.2.1	Display	28
5.2.2	LEDs	28
5.3	First switch on	29
5.4	Access to folders - menu structure	29
5.4.1	"States" menu	29
5.4.1.1	Display Inputs/Outputs (AiL, diL, tCL1/AOL, dOL)	30
5.4.1.2	Setting the clock (CL)	30
5.4.1.3	Alarm Display (AL)	31
5.4.2	Programming menu	31
5.4.2.4	Parameters (folder PAr)	31
5.4.3	Functions (Par/FnC folder)	32
5.4.4	Entering a password (Par/PASS folder)	32
6	Configuration physical I/O (folder PAr/CL.Cr)	33
6.1	Analogue inputs	33
6.1.1	SE6xx SME expansion analogue inputs	33
6.1.2	SKW SKP terminal analogue inputs	33
6.2	Digital Inputs	34
6.3	Digital outputs	34

6.4	Analogue outputs.....	34
7	Parameters (PAr).....	36
7.1	Parameters / visibility table, folder visibility table and client table.....	37
7.1.1	BIOS Parameters / visibility table.....	37
7.1.2	Folder visibility table.....	42
7.1.3	Client Table.....	43
8	Functions (folder FnC)	46
9	Free Studio	47
9.1	General description	47
9.2	Components	47
9.2.1	FREE Studio software component.....	47
9.2.2	DM Interface (DMI) component.....	47
9.2.3	Multi Function Key Component	47
9.2.4	Connection cables	47
10	Monitoring.....	48
10.1	Configuration with Modbus RTU	48
10.1.1	Data format (RTU).....	48
10.1.2	Modbus commands available and data areas	49
10.2	Configuration of device address	49
10.2.1	Configuration of parameter addresses.....	49
10.2.2	Configuration of variable / state addresses.....	49
11	Models and Accessories.....	50
11.1	Models	50
11.1.1	Smart models	50
11.1.2	Expansions	50
11.1.3	Terminals	51
11.2	Accessories.....	52

1 INTRODUCTION

To allow quick, easy reference, the manual has been designed with the following features:

References

References column:

A column to the left of the text contains *references* to subjects discussed in the text to help you locate the information you need quickly and easily.

Cross references

Cross references:

All words in *italics* are listed in the analytical index along with the page number where they are dealt with in more detail. In the "online" (computer) manual, the words in italics are "hyperlinks" (i.e. mouse-clickable links), connecting up the different parts of the manual and making it "navigable".

Highlighting icons:

Some text passages are marked by icons in the *references* column, which have the following meanings:



Important! :

Information that the user must be aware of to prevent any damage to the system or hazards for people, devices, data, etc. Users MUST read and take note of these sections.



Note / highlight:

Further information on the topic in question that the user should be aware of.



Tip:

A suggestion that could help the user to understand and make better use of the information provided.

1.1 General description

FREE Smart is the compact option in the Eliwell platform of programmable controllers, and is ideal for use in a variety of HVAC/R and other applications.

FREE Smart has the same I/O's and variety of *models* as the Flex *range*, which can be combined with Energy Flex *expansions*.

The *models* come in a DIN rail-mounted version which significantly reduces wiring times, or in the regular Eliwell 32x74 format for panel mounting.

FREE Smart also has the same Modbus RTU serial communication standard interface as the Flex *range* and the option of downloading parameter maps and applications via the Multi Function Key.

In association with FREE Smart hardware, the *FREE Studio* development tool is also provided to quickly and reliably program and customize new programmes for any application.

The use of several different programming languages in accordance with IEC61131-3 regulations (programming standard for industrial control), makes it possible to develop new algorithms or entire programmes totally unassisted, which can then be uploaded to Free Smart modules via PC or Multi Function Key, guaranteeing the utmost confidentiality with appropriate security.

Ratiometric pressure sensors, external modules (e.g. fan modules) and *terminals* can also be connected with no need for any further serial interfaces.

1.1.1 Specifications:

FREE Smart SMD4500 – SMC4500 / SME4500 Expansion have disconnectable connectors for both low voltage inputs and relay outputs.

Various *models* are available giving up to 2 *digital inputs*, 4 relay outputs, up to 2 Open Collector PWM *analogue outputs*, up to 2 x 0..10V *analogue outputs*, one configurable 0...20mA/4...20mA output or, alternatively, one 0...10V output on dedicated *models*.

The 4DIN format guarantees maximum flexibility and easy installation.

Power supply 100-240V~

FREE Smart SMP has 2 *models* based on which it is possible to have 6 *digital inputs*, 5 relay outputs, one *TRIAC* output, 2 Open Collector PPM/PWM *analogue outputs*, 3 configurable *analogue outputs* 0...10V/0...20mA/4...20mA and one open collector digital output for external relay.

The standard Eliwell 32x74mm format ensures versatility and ease of installation.

FREE Smart SMD – SMC / SE Expansions come in a variety of *models*, giving you 6 *digital inputs*, up to 5 relay outputs, up to 2 *TRIAC* outputs, up to 2 Open Collector PPM/PWM *analogue outputs*, up to 3 configurable 0...10V/0...20mA/4...20mA *analogue outputs* and up to 2 Open Collector *digital outputs* for an external relay.

The 4DIN format guarantees maximum flexibility and easy installation.

It runs on 12-24V~ or 12-24V~/24V= power supplies.

1.1.2 Main functions of hardware:

- Parameter settings via keyboard or PC
- Multi Function Key (MFK) to download or upload parameter maps
- Terminal (up to 100m cable) with direct connection without serial interface
- Configurable NTC, 0...20mA ,4...20mA, 0...1V, 0...5V, 0...10V inputs or digital input configurable from parameters
- 3 x Pt1000 inputs for 4500 *models*



1.2 Models and Features

-->See Appendix A - *Models and Accessories*, and *Technical Data* section

2 MECHANICAL INSTALLATION

Smart SMP • SKP 10



The instrument is intended for panel mounting (see diagram).



Drill a 29x71 mm hole and insert the instrument; secure it with the special brackets provided.

Do not mount the instrument in damp and/or dirty areas; it is suitable for use in places with ordinary or normal levels of pollution.

Keep the area around the instrument cooling slots adequately ventilated.

The *TTL* serial is on the left side of the device.

Example of installation of SMP • SKP 10 <i>range</i> panel	SMP • SKP 10 ranges panel-mounted
	
<p>The images refer to Smart SMP</p>	


SMP • SKP 10 ranges Example of panel mounting - side view	SMP • SKP 10 ranges Removing the device from the panel – side view
	

SMD – SMC – SE SME ranges




The instrument is intended for 4DIN rail mounting.

For GUIDA DIN installation, follow the steps described below:

- Move the two spring docking devices to their standby position (use a screwdriver to press against the relative compartments).
- Then install the device on the DIN RAIL, pressing on the "spring docking devices" to put them into the locked position.



2.1 Mechanical dimensions



3 ELECTRICAL CONNECTIONS



3.1 General warnings

Before doing anything, make sure the device is connected to a suitable external *transformer*. The following rules must be followed when connecting cards to each other and to the application:

- Loads that exceed the maximum limits set forth in this manual/product *label* must not be applied to outputs.
- When connecting loads, follow connection diagrams carefully.
- To avoid electric pairings, wire all low SELV (*) utilities separately from high voltage ones.

IMPORTANT!

Make sure the machine is switched off before working on the *electrical connections*. All operations must be carried out by qualified personnel. To ensure proper connections, comply with the following:

- Power supplies other than those specified can seriously damage the system.
- Use cables of suitable section for the *terminals* used.
- Separate the cables of probes and *digital inputs* from inductive loads and high voltage connections to prevent any electromagnetic interference. Do not place the probe cables near other electrical equipment (switches, meters, etc.)
- Make connections as short as possible and do not wind them around electrically connected parts.
- To avoid causing static discharges, do not touch the electronic *components* on the boards.
- Eliwell supplies the high voltage cables to connect the device to loads - see *Accessories* chapter
- Eliwell supplies the signal cables to connect the power supply, probes, *digital inputs*, etc - see *Accessories* Chapter.
- The device must be connected to a suitable *transformer* that complies with the specifications provided in the Specifications chapter.



3.1.1 Power supply - High voltage inputs (relay)

Do not exceed the maximum permitted current; for higher loads, use a contactor with sufficient power capacity.

Important!

Make sure that the power supply is of the correct voltage for the device.

3.1.2 TRIAC

The *TRIAC* TC1 output (TC1, TC2 ~ **36xx models**), when partialized, suppresses the half-wave at the zero-crossing.

3.1.3 Analogue Inputs-Probes

Probes have no connection polarity and can be extended using a normal bipolar cable (note that the extension of the probes influences the instrument's EMC electromagnetic compatibility: take great care with the wiring).

Important!

Pressure probes have a specific insertion polarity which must be observed.

Signal cables (temperature/*pressure probes*, *digital inputs*, *TTL* serial) must be wired separately from high voltage cables. Eliwell-supplied probes are recommended. Contact Eliwell sales department for item availability.

Temperature probes



Pressure probes

3.1.4 Serial connections

TTL

Use a 5-wire *TTL* cable up to 30cm in length.

An Eliwell-supplied *TTL* cable is recommended. Contact Eliwell sales department for item availability.
/S models : the *TTL* and RS485 *serials* cannot be used at the same time.




LAN



LAN

3-wire *LAN* 3 powered serial available on the terminal board to connect to the *LAN* network.
Max. distance of 100m between the first and last element in the network.

3.2 Wiring diagrams



55xx *models*



- 5 x 2A 230Vac high voltage *digital outputs* • [DO1, DO2, DO3, DO4, DO6]
- 5 *analogue outputs*:
 - 2 PPM/PWM Open Collector *analogue outputs* [AO1, AO2]
 - 3 low voltage (SELV (§)) *analogue outputs*
 - 2 x 0-10V outputs [AO3-4]
 - 1 output [AO5] 4...20mA/0...20mA
- 6 configurable, no-voltage *digital inputs* (*) [DI1...DI6]
- 5 *analogue inputs*
 - 3 NTC* / Digital Input*** [AI1, AI2, AI5]
 - 2 NTC / voltage, current** / Digital Input*** [AI3, AI4]
- 1 low voltage (SELV (§)) PWM Open Collector output [DO5]

*SEMITEC 103AT type (10KΩ / 25°C)

**0...20mA / 4...20mA current or 0...5V / 0...10V / 0...1V voltage input

or no voltage digital input


***no voltage digital input

(*) closing current for 0.5mA ground

(§) SELV: (SAFETY EXTRA LOW VOLTAGE)

- SUPPLY 12-24V~ / 24V~
- 5 ~ 5Vdc 20mA max. auxiliary supply
- 12 ~ 12Vdc auxiliary supply
- N Neutral
- LAN Connection to terminal (KEYBoard) / SE6xx (max 100m)
- TTL TTL serial to connect a Multi Function Key
- /C RTC
- RS-485 /S integrated RS-485 serial to connect to supervisor

36xx *models*



SMC-SMD36xx(/C/S)

- 3 x 2A 230Vac high voltage *digital outputs* [DO1, DO2, DO3]
- 6 *analogue outputs*:
 - 2 x3A 230Vac high voltage *analogue outputs* [TC1 TC2]
 - 1 PPM/PWM Open Collector analogue output [AO1]
 - 3 low voltage (SELV (§)) *analogue outputs*
 - 2 x 0-10V outputs [AO3-4]
 - 1 output [AO5] 4...20mA/0...20mA
- 6 *digital inputs* [DI1...DI6]
- 5 *analogue inputs* [AI1...AI5]
 - 3 NTC* / Digital Input*** [AI1, AI2, AI5]
 - 2 NTC / voltage, current** / Digital Input*** [AI3, AI4]
- 2 low voltage (SELV (§)) Open Collector outputs [DO5]

*SEMITEC 103AT type (10KΩ / 25°C)

**0...20mA / 4...20mA current or 0...5V / 0...10V / 0...1V voltage input

or no voltage digital input

***no voltage digital input



(°) closing current for 0.5mA ground

(§) SELV: (SAFETY EXTRA LOW VOLTAGE)

- SUPPLY 12-24V~
- 5 ... 5Vdc 20mA max. auxiliary supply
- 12 ... 12Vdc auxiliary supply
- N Neutral
- LAN Terminal (KEYBoard) / SE6xx connection (max 100m)
- TTL TTL serial to connect a Multi Function Key
- /C RTC
- RS-485 /S integrated RS-485 serial to connect to supervisor

(§) SELV: (SAFETY EXTRA LOW VOLTAGE)


46xx *models*



- 4 x 2A 230Vac high voltage *digital outputs* • [DO1, DO2, DO3, DO4]
- 6 *analogue outputs*:
 - 1 high voltage [TC1] 2A 230Vac analogue output
 - 2 PPM/PWM Open Collector *analogue outputs* [AO1, AO2]
 - 3 low voltage (SELV (§)) *analogue outputs*
 - 2 x 0-10V outputs [AO3-4]
 - 1 output [AO5] 4...20mA/0...20mA
- 6 *digital inputs* [DI1...DI6]
- 5 *analogue inputs* [AI1...AI5]
 - 3 NTC* / Digital Input*** [AI1, AI2, AI5]
 - 2 NTC / voltage, current** / Digital Input*** [AI3, AI4]
- 1 low voltage (SELV (§)) PWM Open Collector output [DO5]


*SEMITEC 103AT type (10KΩ / 25°C)
 **0...20mA / 4...20mA current or 0...5V / 0...10V / 0...1V voltage input
 or no voltage digital input
 ***no voltage digital input
 (°) closing current for 0.5mA ground
 (§) SELV: (SAFETY EXTRA LOW VOLTAGE)

- SUPPLY 12-24V~
- 5 ~ 5Vdc 20mA max. auxiliary supply
- 12 ~ 12Vdc auxiliary supply
- N Neutral
- LAN Terminal (KEYBoard) / SE6xx connection (max 100m)
- TTL TTL serial to connect a Multi Function Key
- /C RTC
- RS-485 /S integrated RS-485 serial to connect to supervisor




3.2.1 Example of low voltage input/output connection

Example of current/voltage input connection




Example of Pt1000 input connection (4500 only)


If 1 Pt1000 is set → all three AI1/AI2/AI5 are configured as Pt1000




3.2.2 Example of NTC/DI input connection




3.2.2.1 Example of AO1 / AO2 connection




3.2.2.2 Example of AO3 - AO4/AO5 connection



3.2.2.3 Example of DO5 connection




3.2.3 Example of connection of high voltage outputs




3.3 Network connection examples


3.3.1 Example of Smart SMP → SE6xx connection



3.3.2 Example of Smart SMD/SMC → SE6xx connection




3.3.3 Example of SMC – SKP 10 connection



SMC terminal	SKP 10 terminal	Description
1	1 BLACK	GND / black
2	2 BLUE	Signal / blue
3	3 RED	12V~ power supply from base module

3.3.4 SKW22(L), wall-mounted LCD terminal




Smart	SKW22(L)	description
AIR1		NTC integrated analogue input
1	GND / black	GND / black
2	Signal / Blue	Signal / blue
3	+12Vdc / red**	12V~ power supply from Smart
AIR2	Remote Probe	Probe AIR2 remote analogue input configurable as NTC*/ 4...20mA / DI

* SEMITEC 103AT (10Kohm / 25°C) type

**the transducer can be powered from the +12Vdc terminal

3.3.5 SKW22(L), panel-mounted LCD terminal




Smart	SKP22(L)	description
AIR1	AIR1	NTC/DI integrated analogue input
AIR2	Remote Probe	Remote analogue input configurable as NTC*/ 4...20mA / DI
	GND	Ground
1	GND / black	GND / black
2	Signal / Blue	Signal / blue
3	+12Vdc / red**	12V~ power supply from Smart

* SEMITEC 103AT (10Kohm / 25°C) type

**the transducer can be powered from the +12Vdc

3.3.6 Example of SMC – SE6xx – SKP 10 – LCD terminal connection



1 LCD terminal only

4 TECHNICAL DATA

4.1 General specifications

	Standard	Min.	Max.
Supply voltage 45xx Models	100-240V~		
Supply voltage NOT INSULATED 55xx Models	12-24V~ /24V...		
Supply voltage NOT INSULATED 36xx Models	12-24V~		
Power supply frequency	50Hz/60Hz	---	---
Power draw SMD SMC4500	5W	---	---
Power draw SMP SMD SMC	6VA / 4W	---	---
Power draw SME4500	4.3 W	---	---
Power draw: SE6xx	5VA /3.5W	---	---
Insulation class	2	---	---
Ambient operating temperature	25°C	-20°C	55°C
Ambient operating humidity (non-condensing)	30%	10%	90%
Storage temperature	25°C	-40°C	85°C
Ambient storage humidity (non-condensing)	30%	10%	90%

Classification	
The product complies with the following European Community Directives	Directive 2006/95/EC Directive 89/108/EC
And complies with the following harmonized regulations	EN 60730-2-6 / EN 60730-2-9
Use	operating (not safety) device for incorporation
Mounting	panel or on DIN Omega bar support
Type of action	1.C 1.Y
Pollution class	2
Over voltage category	II
Nominal pulse voltage	2500V
Digital outputs	refer to the label on the device
Fire resistance category	D
Software class	A

4.2 I/O features

Type and Label	Description	Smart				Expansion modules			
		45xx	36xx	46xx	55xx	4500	632	646	655
Digital inputs DI1 DI2	2 no-voltage digital inputs Closing current for ground: 0.5mA Note. For 4500 models , also available as an analogue output (OC: PWM)	x	x	x	x	x	x	x	x
Digital inputs DI3 DI4 DI5 DI6	4 no-voltage digital inputs Closing current for ground: 0.5mA		x	x	x		x	x	x
High voltage digital outputs DO1 DO2 DO3 DO4*	3 x 2A 250V~ relays; For 36xx models , DO4 is available as an Open Collector (OC) output.	DO1 DO2 DO3	*OC	x	x	DO1 DO2 DO3	DO1 DO2 DO3	x	x
DO6	1 x 2A 250V~ relays; Relay output lifetime at nominal rating: 100,000 cycles	x			x	x			x
High voltage analogue output TC1	1 2A TRIAC , max 250V~ Resolution: 1% Remote control switches downstream from the TRIAC are NOT permitted			x				x	
TC1 + TC2 (= AO2)	3A TRIAC , max 250V Resolution: 1% Remote control switches downstream from the TRIAC are NOT permitted		x						

Type and <i>Label</i>	Description	Smart				Expansion modules			
		45xx	36xx	46xx	55xx	4500	632	646	655
PWM/PPM OC low voltage (SELV) <i>analogue outputs</i> AO1 AO2	Open Collector PWM/PPM outputs Accuracy: 2% Nominal <i>range</i> 0...16.9V _{rms} (12V _{rms} rectified) Closing at 12V _{rms} ** Max. current 35mA ** (min. load 340Ohm @12Vcc)	OC: PWM	AO2 = TC2 (TRIAC)	x	x	OC: PWM	x	x	x
Low voltage (SELV) <i>analogue outputs</i> AO3 AO4	0-10V max 28mA *** @10V outputs (min. 360 Ohm load resistance) 2% full scale accuracy Resolution: 1%	x	x	x	x	x		x	x
AO5	1 x 4..20mA / 0...20mA output 2% full scale accuracy Resolution: 1% <ul style="list-style-type: none"> 0/4...20mA output, max load (max load resistance 350Ohm)*** 	x	x	x	x	x		x	x
AO5	1 x 0...10V output on dedicated model 2% full scale accuracy Resolution: 1%	x				x			
<i>Analogue inputs</i> AI1 AI2 AI5	3 configurable inputs: Pt1000 temperature, measurement <i>range</i> -50°C ÷ 400°C; Accuracy: 1% full scale Resolution: 0.1	x							
<i>Analogue inputs</i> AI1 AI2 AI5	3 configurable inputs: a) NTC temperature 103AT 10kΩ, measurement <i>range</i> -50°C ÷ 99.9°C; b) no voltage digital input Accuracy: 1% full scale Resolution: 0.1	x	x	x	x	x	x	x	x
<i>Analogue inputs</i> AI3 AI4	2 configurable inputs: a) NTC temperature 103AT 10kΩ, measurement <i>range</i> -50°C ÷ 99.9°C. b) 0...20mA/4...20 mA current input/0-10V/0-5V/0-1V voltage input measurement <i>range</i> -50.0 ÷ +99.9; c) no voltage digital input Accuracy: <ul style="list-style-type: none"> 0-10V 1% full scale 0-5V: 1% full scale 0-1V: 2% full scale 0...20mA /4...20mA: 1% full scale Resolution: 0.1 Input impedance (b): <ul style="list-style-type: none"> 0-10V 21KOhm 0-5V: 110KOhm 0-1V: 110KOhm 0...20mA / 4...20mA: 100Ohm 		x	x	x	x		x	x
Open Collector low voltage (SELV) digital output DO4*, DO5	2 x Open Collector outputs ** Max. current 35mA ** @12VDC		x						
DO5	1 x Open Collector output ** Max. current 35mA ** @12VDC			x	x		x	x	x

*On SMD/SMC36xx *models*, DO4 is an open collector, TC2 equals AO2 (TC2=AO2) - see chapter entitled Physical I/O Configuration (PAR/CL..Cr *folder*)

** Outputs AO1, AO2 and DO5 (typically connected to the device's auxiliary 12V \sim output) cannot deliver more than 70mA in total. Any other loads connected to the same 12V \sim auxiliary output must also be taken into account.



If the SKP 10 keypad is connected to the device, the current becomes 55mA.

***Outputs AO3, AO4 and AO5 cannot deliver more than 40mA total.

4.3 Mechanical specifications

	Description	All <i>models</i> except for 4500	4500 <i>models</i>
	Terminals and connectors		
High voltage	1 x 8-way high voltage male connector For use in combination with the supplied female connector	✓	-
	1 x 2-way high voltage male connector For use in combination with the supplied female connector	-	✓
	1 x 7-way high voltage male connector For use in combination with the supplied female connector	-	✓
Low voltage	1 x 20-way snap-on low voltage connector To be used with COLV0000E0100	✓	-
	1 x 12-way low voltage male connector For use in combination with the supplied female connector	-	✓
	1 x 4-way connector To be used with COLV000042100	✓	-
terminal	1 x 3-way LAN connector and terminal To be used with COLV000033200	✓	✓
RS485 serial /S <i>models</i>	1 x 3-way connector To be used with COLV000035100	/S <i>models</i>	-
	1 x 3-way low voltage male connector For use in combination with the supplied female connector	-	/S <i>models</i>
	Container		
	PC+ABS plastic resin with V0 flammability rating	All <i>models</i>	All <i>models</i>

4.4 Serials

Type	Label	Description	Models
<i>Serials</i>	TTL	1 TTL serial to connect CopyCard (MFK) or Personal Computer via interface module	All <i>models</i>
	RS-485	RS-485 opto-isolated serial	/S <i>models</i>

4.5 Transformer

All *models* except 4500

FREE Smart must be connected to a suitable current *transformer* with the following features:

- Primary voltage: Depending on requirements of the individual device and/or country of installation.
- Secondary voltage: 12V \sim
- Power supply frequency: 50/60Hz
- Power: 6VA min. (/S *models*), 5VA (all other *models*)

4.6 Mechanical dimensions

	Length (L) mm	Depth (d) mm	Height (H) mm	Notes
SMP front panel SKP 10	76.4	//	35	(+0.2mm)
SMD SMC front panel (cover) SE6xx SME	70	//	45	(+0.2mm)
SMP dimensions	86	76 connectors excluded	26	
SMD SMC dimensions SE6xx SME	70.2	61.6 56.4 from Din bar to cover	87	4DIN
Hole for panel-mounting SMP SKP 10	71	//	29	(+0.2mm /-0.1mm)

4.7 Permitted use

For safety reasons, the device must be installed and used in accordance with the instructions provided. In particular, parts carrying dangerous voltages must not be accessible under normal conditions.

The device must be adequately protected from water and dust with regard to the application, and must only be accessible using tools (with the exception of the front panel).

The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested for safety aspects in accordance with harmonized European reference standards.

4.8 Improper Use

Any use other than that expressly permitted is prohibited.

The relay contacts supplied are of the functional type and are subject to fault (since they are electronically controlled they are prone to short-circuiting or remaining open). Any protection devices specified in product standards or suggested by common sense for obvious safety requirements must be installed externally to the device.

Eliwell is not liable for damage caused by:

- Unspecified installation/use and, in particular, in contravention of the safety requirements of established legislation or specified in this document;
- Use on equipment which does not provide adequate protection against electrocution, water and dust in the actual installation conditions;
- Use on equipment in which dangerous *components* can be accessed without the use of specific tools;
- Installation/use on equipment which does not comply with established legislation and standards.


4.9 Disclaimer


This document is the exclusive property of **Eliwell Controls srl** and may not be reproduced or circulated unless expressly authorized by **Eliwell Controls srl** itself.

Every care has been taken in preparing this document; however, **Eliwell Controls srl** cannot accept liability for any damage resulting from its use.

5 USER INTERFACE (FOLDER PAR/UI)

The front panel of the device functions as the user interface and is used to perform all operations relating to the device.



SKP 10 terminal	
	<p>Note: The SMC module does not have a <i>display</i>. To operate the device, use the SKP 10 or SKW22(L) – SKP22(L) terminal.</p> <p>The SExx / SME expansion module does not have a <i>display</i>.</p>

5.1 Keys

Refer to [models](#) SMP/SMD and SKP 10.

Key	Press once (press and release)	Key [depending on the application; press for Ui26 seconds]
▲ UP (UP)	<ul style="list-style-type: none"> Increase a value Go to next <i>label</i> 	F1
▼ DOWN (DOWN)	<ul style="list-style-type: none"> Decrease a value Go to previous <i>label</i> 	F3
Esc(ape) Exit (Without saving new settings)	<ul style="list-style-type: none"> Exit without saving new settings Go back to previous level 	F2
Set Confirm (and save new settings)	<ul style="list-style-type: none"> Confirm value / exit and save new settings Move to next level (open <i>folder</i>, subfolder, parameter, value) Open state Menu 	F4

The following indications refer to the SMP FREE Smart user interface. Navigation for SMD and SKP10 is the same.

5.1.1 Description of keys – combined action

Symbol (function when <i>keys</i> are pressed together)	Combined pressing Single press (press and release)	(Associated Function)
F5	[F1+F3]	[Lets you switch from the BIOS menu in the main <i>display</i> to the main <i>display</i> of the PLC menu (if present)] See <i>FREE Studio</i> Quick Start for details
Prg	[F2+F4]	(Open <i>programming menu</i>)

5.2 LEDs and Display








The *display* has 18 icons (*LEDs*) split into 3 categories:







1. States and Operating Modes
2. Values and Units of Measure
3. Utilities



5.2.1 Display

Values of up to 4 figures or 3 figures plus a sign can be displayed.


5.2.2 LEDs

LED states and Operating Modes	Icons	Description	Colour
 <p>The <i>display</i> shows the value/resource set for the "main <i>display</i>".</p> <p>The Alarm icon lights up if there is an alarm.</p>		Alarm	Red
		Heating	Green
		Cooling	
		Standby	
		Defrost	
		Economy	

LED Unit of measure	Icons	Description	Colour
		Clock (RTC)	Red
		Degrees centigrade	
		Pressure (Bar)	
		Relative humidity transducer RH	
		Menu (ABC)	

LED utilities	Icons	Description	Colour
		Utility	Amber

5.3 First switch on

	<p>When FREE Smart is powered on for the first time, a lamp test is carried out to check its state and operation.</p> <p>-----</p> <p>The Lamp Test lasts for a few seconds. During this short time, all <i>LEDs</i> and digits flash at the same time.</p>
---	---

5.4 Access to folders - menu structure

Access to folders is organised into menus.

Access is determined by the *keys* on the front panel (see relative sections).

Access to each individual menu is explained below (or in the sections indicated). There are 2 menus:

- "*States*" menu → see "*States Menu*" section;
- "Programming" Menu → see "*Programming Menu*" section.

There are 3 folders/submenus in the *Programming Menu*:

- Parameters Menu (PAR *folder*) → see Parameters chapter.
- Functions Menu (Fnc *folder*) → see Functions chapter.
- PASS Password

5.4.1 "States" menu

From the states menu you can view values for each resource.




The resources may be present / not present depending on the model (e.g dOL6 is only present on Smart SMP/SMD/SMCxxxx).

Label							Description	Change
Ai	AIL1	AiL2	AIL3	AIL4	AIL5		LOCAL <i>analogue inputs</i>	//
Ai	AIE1	AiE2	AIE3	AIE4	AIE5		EXTENDED <i>analogue inputs</i> (§)	//
Ai	Air1	Air2					TERMINAL <i>analogue inputs</i>	//
di	diL1	diL2	diL3	diL4	diL5	diL6	LOCAL <i>digital inputs</i>	//
di	diE1	diLE2	diE3	diE4	diE5	diE6	EXTENDED(§) <i>digital inputs</i>	//
AO	tCL1	AOL1	AOL2	AOL3	AOL4	AOL5	LOCAL <i>analogue outputs</i>	//
AO	tCE1	AOE1	AOE2	AOE3	AOE4	AOE5	EXTENDED(§) <i>analogue outputs</i>	//
dO	dOL1	dOL2	dOL3	dOL4	dOL5	dOL6	LOCAL <i>digital outputs</i>	//
dO	doE1	doE2	doE3	doE4	doE5	doE6	EXTENDED(§) <i>digital outputs</i>	//
CL	HOUr	dAtE	YEAr				Clock	YES
AL	Er45	Er46					Alarms	//

(§) Only if SE6xx expansion module is present.

As you will be able to see from the table, the time can be modified and viewed:










5.4.1.1 Display Inputs/Outputs (AiL, diL, tCL1/AOL, dOL)

Inputs/Outputs <i>display</i>		
		
<p>Example of view for <i>Analogue Inputs</i>. The same procedure applies to all other I/Os***</p> <p>The <i>label</i> Ai will appear on the <i>display</i>.</p> <p>(Use the UP and DOWN <i>keys</i> to scroll the other labels until you find the <i>label</i> required).</p>	<p>Press the set key to view the <i>label</i> for the first analogue input (AiL1 in this case).</p>	<p>Press the set key again to view the value of AiL1. Note that the °C icon lights up to indicate that the value shown is in degrees centigrade.</p> <p>-----</p> <p>Press the esc key to go back to the main <i>display</i>.</p>




***For *digital inputs/analogue inputs* configured as digital, the value will be:
 - 0 = Input not active (for *digital inputs* this is equivalent to input open, for *analogue inputs* configured as digital this is equivalent to input shortcircuited to ground).
 - 1 = Active input (for *digital inputs* this is equivalent to input shortcircuited to ground, for *analogue inputs* configured as digital it is equivalent to input open).

5.4.1.2 Setting the clock (CL)

FREE Smart has a clock (RTC) to run the alarm history just like a programmable chronothermostat. Instructions are provided below on how to set the time: the same procedure applies to change the date and year.

Setting clock		
		
<p>To change the clock on your machine, press the set key from the main <i>display</i>.</p>	<p>Pressing the set key once will open a list of the various folders. Use the "UP" and "DOWN" <i>keys</i> to find the <i>CL folder</i>.</p>	<p>Press the set key to open the CL menu.</p>
		
<p>On entering this menu, you will see HOUR. Use the "UP" and "DOWN" <i>keys</i> to select the time, date or year.</p> <p>Once you have decided what you want to set, press the [set]** key to open the modification menu for the variable selected. **press and hold for about 3 seconds.</p>		
		
<p>To set the time, date and year, use the "UP" and "DOWN" <i>keys</i> to enter the required value, then</p>	<p>Press set.</p>	<p>Press the Esc key to exit the set clock menu and go back to the main <i>display</i>.</p>

5.4.1.3 Alarm Display (AL)

Alarm <i>display</i>		
Press the set key from the main <i>display</i>		
		
The <i>label</i> Ai will appear on the <i>display</i> . Use the UP and DOWN <i>keys</i> to browse the other labels until you find the AL <i>label</i> .	Press the set key to view the <i>label</i> of the first active alarm (if it exists).	In this case, the first alarm is Er01. Use the UP and DOWN <i>keys</i> to scroll any other alarms. Note: the menu is not cyclical. For example, if the active alarms are Er45 and Er46, the <i>display</i> will show: Er45 ->Er46<Er45 Note: -> UP, <-DOWN Press the esc key to go back to the main <i>display</i> .







5.4.2 Programming menu




Parameters	Parameter	CL	Cr	CF	Ui	Parameters
Functions	FnC					Functions
Password	PASS					Password

5.4.2.4 Parameters (folder PAR)

Modifying a parameter

Instructions are provided below on how to change a machine parameter. By way of example, let's look at the CL configuration parameters *folder*, parameter CL01 (*folder* PAR/CL/CL01).

Modifying a parameter -1		
		
Press the esc and set <i>keys</i> together to open the parameters menu. This will open the PAR menu.	The PAR parameters menu contains all device parameter folders. Press the set key to view all folders.	The first <i>folder</i> the controller shows is the CL configuration <i>folder</i> . Simply press the set key again to modify individual CL parameters.
		
--> continued on page next		




Modifying a parameter -2		
		
<p>The CL00 parameter will be shown on the device (factory <i>default</i> settings).</p> <p>Press the "up" key to scroll through the various parameters or move to the next parameter (CL01 in this case) or the "down" key to go back to the previous parameter</p>	<p>Press the set key to view the value of the parameter (CL01 in this case).</p>	<p>For parameter CL01, the value shown will be 2. Press the "up" and "down" <i>keys</i> to modify this value.</p> <p>Press the set key once you have entered the required value. **</p> <p>Press the esc key to exit this <i>display</i> and go back to the previous level.</p> <p>**N.B. pressing the set key will confirm the value entered; Pressing the esc key will take you back to the previous level without saving the value entered.</p>

5.4.3 Functions (Par/FnC folder)

See Functions chapter (*folder* FnC)

5.4.4 Entering a password (Par/PASS folder)

To view parameters visible for the given password, open *folder* PASS (press esc and set together [esc+set] from the main *display* and search the *folder* using the up/down *keys*) and set the PASS value.

Setting password		
		
<p>Press the esc and set <i>keys</i> together from the main <i>display</i> to enter the PASS <i>folder</i>. [esc+set]</p>	<p>Pressing the two <i>keys</i> will open the menu containing the list of folders. Use the "up" and "down" <i>keys</i> to scroll the list until you find the PASS <i>folder</i>.</p>	<p>Press the set key to open the PASS <i>folder</i>.</p> <p>Enter the password (installation or manufacturer) from here, press the set key and exit.</p> <p>Now open and view parameters to change a value (see parameters chapter).</p>

6 CONFIGURATION PHYSICAL I/O (FOLDER PAR/CL..CR)

6.1 Analogue inputs

Free Smart analogue inputs

The *analogue inputs* referred to below as AiL1...AiL5 are 5 in total.

Using the parameters, a physical resource (probe, digital input, voltage/current signal) can be "physically" configured for each type of input:

- 3 inputs can be configured as *temperature probes*, an NTC type probe, or as *digital inputs*.
- 2 inputs (AiL3 and AiL4) can be configured as *temperature probes*, an NTC type probe, as *digital inputs* or current/voltage input (signal 0-20mA / 4-20mA / 0-10V, 0-5V, 0-1V).

6.1.1 SE6xx SME expansion analogue inputs

SE6xx analogue inputs

The *analogue inputs* referred to below as AiE1...AiE5 are 5 in total.

Using the parameters, a physical resource (probe, digital input, voltage/current signal) can be "physically" configured for each type of input:

- 3 inputs can be configured as *temperature probes*, an NTC type probe, or as *digital inputs*.
- 2 inputs (AiE3 and AiE4) can be configured as *temperature probes*, an NTC type probe, as *digital inputs* or current/voltage input (signal 0-20mA / 4-20mA / 0-10V, 0-5V, 0-1V).

6.1.2 SKW SKP terminal analogue inputs

SKW SKP analogue inputs

The *analogue inputs* referred to below as AiR1...AiR2 are 2 in total.

Using the parameters, a physical resource (probe, digital input, voltage/current signal) can be "physically" configured for each type of input:

- 1 input configurable as NTC type temperature probe.
- 1 input configurable as NTC type temperature probe, digital input or current input (0-20mA/4-20mA signal).

Inputs can be "physically" configured as specified in the table below.

Analogue inputs: table

	Par	Description	0	1*	2	3	4	5	6	7	8
Smart	CL00	Type of analogue input AiL1	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	//
	CL01	Type of analogue input AiL2	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	Pt1000 4500 models only
	CL02	Type of analogue input AiL3	Probe not configured	Probe configured as no voltage digital input	NTC sensor	4-20 mA	0-10 V	0-5 V	0-1 V	0-20 mA	Pt1000 4500 models only
	CL03	Type of analogue input AiL4	Probe not configured	Probe configured as no voltage digital input	NTC sensor	4-20 mA	0-10 V	0-5 V	0-1 V	0-20 mA	//
	CL04	Type of analogue input AiL5	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	Pt1000 4500 models only
SE SME	CE00	Type of analogue input AiE1	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	//
	CE01	Type of analogue input AiE2	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	//
	CE02	Type of analogue input AiE3	Probe not configured	Probe configured as no voltage digital input	NTC sensor	4-20 mA	0-10 V	0-5 V	0-1 V	0-20 mA	//
	CE03	Type of analogue input AiE4	Probe not configured	Probe configured as no voltage digital input	NTC sensor	4-20 mA	0-10 V	0-5 V	0-1 V	0-20 mA	//
	CE04	Type of analogue input AiE5	Probe not configured	Probe configured as no voltage digital input	NTC sensor	//	//	//	//	//	//
SKW22 SKP22	Cr00	Type of analogue input AiR1	Probe not configured	//	NTC sensor	//	//	//	//	//	//
	Cr01	Type of analogue input AiR2	Probe not configured	Probe configured as no voltage digital input	NTC sensor	4...20mA	//	//	//	0-20 mA	//
Note: // indicates that value is not present											
*See Configuration of <i>Digital Inputs</i>											

	Analogue input AI	Parameter	range	Description
Smart	AiL3	CL10	CL11...99.9	Analogue input AiL3 full scale value
	AiL3	CL11	-50.0...CL10	Analogue input AiL3 start of scale value
	AiL4	CL12	CL13...99.9	Analogue input AiL4 full scale value
	AiL4	CL13	-50.0...CL12	Analogue input AiL4 start of scale value
SE SME	AiE3	CE10	CE11...99.9	Analogue input AiE3 fullscale value
	AiE3	CE11	-50.0...CE10	Analogue input AE3 start of scale value
	AiE4	CE12	CE13...99.9	Analogue input AiE4 fullscale value
	AiE4	CE13	-50.0...CE12	Analogue input AiE4 start of scale value
SKW22 SKP22	Air2	Cr10	CR11...99.9	Analogue input Air2 fullscale value
	Air2	Cr11	-50.0...Cr10	Analogue input Air2 start of scale value

The values read by *analogue inputs* can be calibrated using parameters CL20...CL24 / CR20...CR21

	Parameter	Description	Measurement Unit	Range
Smart	CL20	Analogue input AiL1 differential	°C	-12.0..12.0
	CL21	Analogue input AiL2 differential	°C	-12.0..12.0
	CL22	Analogue input AiL3 differential	°C / Bar	-12.0..12.0
	CL23	Analogue input AiL4 differential	°C / Bar	-12.0..12.0
	CL24	Analogue input AiL5 differential	°C	-12.0..12.0
Expansion SE SME	CE20	Analogue input AiE1 differential	°C	-12.0..12.0
	CE21	Analogue input AiE2 differential	°C	-12.0..12.0
	CE22	Analogue input AiE3 differential	°C / Bar	-12.0..12.0
	CE23	Analogue input AiE4 differential	°C / Bar	-12.0..12.0
SKW	Cr20	Analogue input Air1 differential	°C	-12.0..12.0
	Cr21	Analogue input Air2 differential	°C / Bar	-12.0..12.0

6.2 Digital Inputs

Digital Inputs The no voltage *digital inputs* referred to below as DI1...DI6 are 6 in total.

6.3 Digital outputs

Digital outputs See the chapter on Electric Connections for the number and capacity of relays/open collectors and for information on the symbols used on labels supplied with the device.

- High voltage outputs (relays) are identified as DO1, DO2, DO3, DO4 and DO6.
- The low voltage (SELV), open collector output is called DO5.

6.4 Analogue outputs

Analogue outputs See the chapter on Electric Connections for the number and type of *analogue outputs* used and for information on the symbols used on labels supplied with the device. There are 6 *analogue outputs*. 1 high voltage one and 5 low (SELV) voltage ones, the exact number depending on the following *models* and with the following characteristics:

Table A2 – *Analogue Outputs* and *Models*

Output	Label on display	High voltage		SELV			Smart models			Expansion models			
		36xx free Smart models	46xx free Smart models	Open Collector PWM/PPM	0-10V	0...20mA 4...20mA	36xx	46xx	55xx	632	636	646	655
TC1	TCL1	3A 230V	2A 230V				•	•					
TC2	TCL2	3A 230V					•						
AO1	AOL1			•			•	•	•				
AO2	AOL2			•				•	•				
AO3	AOL3				•		•	•	•				
AO4	AOL4				•		•	•	•				
AO5	AOL5					•	•	•	•				
TC1	TCE1	3A 230V	2A 230V							•	•	•	
TC2	TCE2	3A 230V								•			
AO1	AOE1			•						•	•	•	•
AO2	AOE2			•						•		•	•
AO3	AOE3				•						•	•	•
AO4	AOE4				•						•	•	•
AO5	AOE5					•					•	•	•



Triac Analogue Outputs (TC1, TC2)

One **TRIAC** output is a high voltage one and is generally used to pilot fans or water pumps. The output can be configured for proportional operation (constant speed variation) or as ON/OFF. **Remote control switches downstream from the *Triac* are NOT permitted**

The output can be configured as described in table “*Analogue Output TC1 - AO1 AO2*: table”. **Configuration of low voltage (SELV) analogue output**

AO1	AO2	AO3-AO4	AO5
always available. Configurable as: PWM/PPM (via CFS modules) or On/Off)	always available. Configurable as: PWM/PPM (via CFS modules) or On/Off)	low voltage (SELV) output to pilot external modules (e.g. to control fans).	low voltage (SELV) output to pilot external modules to run fans. It can be used to pilot 4-20mA fans or 0-20mA fans (via parameter CL60/CE60)

To configure, see the table below. All *analogue outputs* can be configured as digital or proportional. **Table B – Analogue Outputs**

Analogue output
TC1 - AO1 AO2

Output	Parameter	Description	Values	Notes
TC1 Only <i>models</i> 36x 46x SE636 SE646	CL73 CE73	Analogue output TCL1 phase shift Analogue output TCE1 phase shift	0...90	Phase shift values to pilot <i>Triac</i> with cut-off in the event of inductive loads.
	CL76 CE76	Analogue output TCL1 pulse time Analogue output TCE1 pulse time	5...40 units (347...2776 µs)	Pulse length to pilot <i>Triac</i> (1 unit = 69.4 µs).
TCL1	CL70	Enable <i>TRIAC</i> TCL1 output	0= 55x <i>models</i>	
			1= 46x <i>models</i>	See CL73 – CL76
TCE1	CE70	Enable <i>TRIAC</i> TCE1 output	0= SE655 <i>models</i>	
			1= SE636/SE646 <i>models</i>	See CE73 – CE76
AO1	CL71 CE71	Enable AOL1 analogue output Enable AOE1 analogue output	0= Output configured as digital	If=0 see parameter CL96 /CE96
			1= Output configured as <i>Triac</i>	(for pulse pilot) If =1 see parameters CL74 – CL77 – CL80 CE74 – CE77 – CE80
	CL74 CE74	Analogue output AOL1 phase shift Analogue output AOE1 phase shift	0...90	Active if CL71=1 / CE71=1
	CL77 CE77	Analogue output AOL1 pulse time Analogue output AOE1 pulse time	5...40 units (347...2776 µs)	Active if CL71=1 / CE71=1 (1 unit = 69.4 µs).
AO2 *	CL72 CE72	Enable AOL2 analogue output Enable AOE2 analogue output	0= Output configured as digital	If=0 see parameter CL97 / CE97
			1= Output configured as <i>Triac</i>	(for pulse pilot) If =1 see parameters CL75 – CL78 – CL81 CE75 – CE78 – CE81
	CL75 CE75	Analogue output AOL2 phase shift Analogue output AOE2 phase shift	0...90	Active if CL72=1 /CE72=1
	CL78 CE78	Analogue output AOL2 pulse time Analogue output AOE2 pulse time	5...40 units (347...2776 µs)	Active if CL72=1 /CE72=1 (1 unit = 69.4 µs).

* In 36xx Smart – SE636 *models* AO2 is used as *TRIAC* (TC2).

SELV analogue
output AO3-4-5

Parameter	Description	Values
CL60 CE60	Type of analogue output AOL5 Type of analogue output AOE5	0=4-20mA Current analogue output 1=0-20mA Current analogue output 2=0-10V on dedicated model

The following can be piloted:

- Loads with output modulation or
- Loads with on/off type switching using
 - the *Triac* as switch (TC1 AO1 AO2).
 - the output as switch 0-10V (AO3-4).
 - the output as switch 0/4...20mA (AO5).

7 PARAMETERS (PAR)

Parameters are used to configure every aspect of free Smart;

They can be modified with:

- The Multi Function key (MFK).
- [Keys](#) on SMP/SMD front panel or SKP 10/SKW22(L)/SKP22(L) terminal.
- Personal computer and [free Studio](#) software.

THE DEVICE MUST BE TURNED OFF AND SWITCHED ON AGAIN AFTER BIOS PARAMETERS MODIFICATION

The following sections analyse each parameter, divided into categories (folders), in detail.

Each [folder](#) is designated with 2 figures (example: CF, UI, etc).

Folder label	Acronym meaning (label)	Parameters of:
CL	Configuration Local	Local I/O configuration
CE	Configuration Expansion	Configuration I/O Expansion
Cr	Configuration terminal	Terminal I/O configuration
CF	Configuration	Configuration
UI	User interface	User interface

Visibility and value of Parameters

Free Smart is a family of programmable controllers.

There are various hardware [models](#) (see [Models](#)) with varying numbers of inputs/outputs.

Depending on the model, some configuration parameters may not be visible and/or of any significance given that the associated resource is not present.

Levels of visibility

Four levels of visibility can be set by assigning suitable values to each parameter and [folder](#), by [serial](#), [software](#) ([free Studio](#) or other communication softwares) [or by programming key](#).

The visibility levels are:

- Value 3 = parameter or [folder](#) always visible.
 - Value 2 = **manufacturer level**; These parameters can only be seen by entering the manufacturer's password (see parameter Ui28) (all parameters specified as always visible, parameters that are visible at the installation level, and manufacturer level parameters will be visible).
 - Value 1 = **installation level**; these parameters can only be viewed by entering the installation password (see parameter Ui27) (all parameters specified as always visible and parameters that are visible at the installation level will be visible).
 - Value 0 = parameter or [folder](#) NOT visible.
1. Parameters and/or folders with visibility level <>3 (i.e. password protected) will only be visible if the correct password is entered (installer or manufacturer) following the procedure outlined below:
 2. Parameters and/or folders with visibility level =3 are always visible and no password is required; in this case, the procedure below is not required.

Refer also to the following table:

	hardware	TCL1 TCE1	TCL2 TCE2	DOL6 DOE6
Smart Model	36xx	CL73-CL76 CE73-CE76	CL75-CL78 (AOL2) CE75-CE78 (AOE2)	
	46xx/C 46xx/C/S	CL73-CL76 CE73-CE76		//
	55xx/C 55xx/C/S	//	//	//
	4500	//	//	//

When not indicated otherwise, the parameter is always visible and modifiable, unless customised settings have configured via serial.

Note: parameters and [folder](#) visibility can both be controlled (See [Folder table](#)).

If [folder](#) visibility is modified, the new setting will apply to all parameters in the [folder](#).

7.1 Parameters / visibility table, folder visibility table and client table

The **tables below** list all information required to read, write and decode all accessible resources in the device.

There are three tables:

- The **parameter table** contains all device configuration parameters stored in the non-volatile memory of the instrument, including visibility information.
- The **folders table** lists the visibility of all parameter folders.
- The **client table** includes all I/O and alarm status resources available in the volatile memory of the instrument.

Description of columns:

FOLDER	This indicates the <i>label</i> of the <i>folder</i> containing the parameter in question.
LABEL	This indicates the <i>label</i> used to <i>display</i> the parameters in the device menu.
VAL PAR ADDRESS	Indicates the address of the modbus register containing the resource you wish to access.
VIS PAR ADDRESS	Same as above. In this case, the parameter visibility value is in the MODBUS register address. By <i>default</i> , all parameters have <ul style="list-style-type: none"> • <i>Data size</i> WORD • <i>Range</i> 0...3** • <i>U.M.</i> num
	** See Setting Password (<i>folder</i> Par/PASS) paragraph, User Interface chapter.
VIS PAR VALUE	Indicates parameter / <i>folder</i> visibility <ul style="list-style-type: none"> ○ 0 = Never visible. Not visible from device ○ 1 = Level 1 – see Ui27 ○ 2 = Level 2 – see Ui28 ○ 3 = Always visible.
R/W	Indicates if resources are read/write, read-only or write-only: <ul style="list-style-type: none"> R Read-only resource W Write-only resource RW Read / write resource
DATA SIZE	Indicates the size of the data in bits. The dimension is always in WORD = 16 bit.
CPL	When the field indicates "Y", the value read by the register requires conversion, because the value represents a number with a sign. In the other cases the value is always positive or null. To carry out conversion, proceed as follows: <ul style="list-style-type: none"> • If the value in the register is between 0 and 32.767, the result is the value itself (zero and positive values). • If the value in the register is between 32.768 and 65.535, the result is the value of the register – 65.536 (negative values).
RANGE	Describes the interval of values that can be assigned to the parameter. It can be correlated with other instrument parameters (indicated with the parameter <i>label</i>). NOTE: If the actual value is outside the limits specified for the parameter itself (for example, because other parameters defining the limits in question have been varied), instead of the actual value the <u>value of the limit not respected is displayed</u> .
DEFAULT	Indicates the factory setting for the standard model of the instrument. <u>In this table, the hardware model can be presumed to be SMP/SMD/SMC46xx/C with 4 relays + TRIAC + 2 AO1 AO2 Open Collector PWM/PPM analogue outputs + 1 low voltage analogue output A03.</u>
EXP	If = -1 the value read from the register is divided by 10 (value/10) to convert it to the values given in the <i>RANGE</i> and <i>DEFAULT</i> column and the unit of measure specified in the <i>U.M. column</i> ., Example: parameter CL04 = 50.0. Column <i>EXP</i> = -1: <ul style="list-style-type: none"> • The value read by the device <i>/free Studio</i> is 50.0 • The value read from the register is 500 --> 500/10 = 50.0
U.M.	Measurement unit for values converted according to the rules indicated in the <i>CPL</i> and <i>EXP</i> columns. Measurement unit listed shall be considered as an example – it could depends on the application developed (i.e. parameters with <i>U.M.</i> °C/bar could have <i>U.M.</i> %RH)

7.1.1 BIOS Parameters / visibility table

(See next page).

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	EXP	VIS PAR ADDRESS	VIS PAR VALUE	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
CL	CL00	53304	WORD			53585	2	RW	Type of analogue input Ai1 <ul style="list-style-type: none"> • 0= Probe not configured • 1= DI • 2 = NTC • 3...7 = NOT USED • 8= Pt1000 (4500 <i>Models</i> only) 	0 ... 8	0	num
CL	CL01	53305	WORD			53586	2	RW	Type of analogue input Ai2 See CL00	0 ... 8	0	num
CL	CL02	53306	WORD			53587	2	RW	Type of analogue input Ai3 <ul style="list-style-type: none"> • 0= Probe not configured • 1= DI • 2 = NTC • 3=4..20mA • 4=0-10V • 5=0-5V • 6=0-1V • 7= 0..20mA 	0 ... 7	0	num
CL	CL03	53307	WORD			53588	2	RW	Type of analogue input Ai4 See CL02	0 ... 7	0	num
CL	CL04	53308	WORD			53589	2	RW	Type of analogue input Ai5 See CL00	0 ... 8	0	num
CL	CL10	15649	WORD	Y	-1	53590	1	RW	Analogue input Ai3 full scale value	CL11 ... 999	500	°C/Bar
CL	CL11	15655	WORD	Y	-1	53591	1	RW	Analogue input Ai3 start of scale value	-500 ... CL10	0.0	°C/Bar
CL	CL12	15650	WORD	Y	-1	53592	1	RW	Analogue input Ai4 full scale value	CL13 ... 999	500	°C/Bar
CL	CL13	15656	WORD	Y	-1	53593	1	RW	Analogue input Ai4 start of scale value	-500 ... CL12	0	°C/Bar
CL	CL20	53334	WORD	Y	-1	53594	1	RW	Analogue input Ai1 differential	-120 ... 120	0	°C
CL	CL21	53335	WORD	Y	-1	53595	1	RW	Analogue input Ai2 differential	-120 ... 120	0	°C
CL	CL22	53336	WORD	Y	-1	53596	1	RW	Analogue input Ai3 differential	-120 ... 120	0	°C/Bar
CL	CL23	53337	WORD	Y	-1	53597	1	RW	Analogue input Ai4 differential	-120 ... 120	0	°C/Bar
CL	CL24	53338	WORD	Y	-1	53598	1	RW	Analogue input Ai5 differential	-120 ... 120	0	°C
CL	CL60	53344	WORD			53599	2	RW	Type of analogue output AOL5 <ul style="list-style-type: none"> • 0 = 4-20mA • 1 = 0-20mA • 2 = 0-10V on dedicated model 	0 ... 2	0	num
CL	CL70	53346	WORD			53600	0	RW	Enable TRIAC output TCL1 <ul style="list-style-type: none"> • 0 = 55xx <i>models</i> • 1 = 46xx – <i>models</i> see CL73 – CL76 	0 ... 1	0	num

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	EXP	VIS PAR ADDRESS	VIS PAR VALUE	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
CL	CL71	53347	WORD			53601	2	RW	Enable analogue output AOL1 <ul style="list-style-type: none"> 0 = Output configured as digital 1 = 46xx – <i>models</i> see CL74 – CL77 	0 ... 1	0	num
CL	CL72	53348	WORD			53602	2	RW	Enable analogue output AOL2 <ul style="list-style-type: none"> 0 = Output configured as digital 1 = output configured as <i>Triac</i> – see CL75 – CL78 	0 ... 1	0	num
CL	CL73	53349	WORD			53603	0	RW	Analogue output TCL1 phase shift	0 ... 90	27	Deg
CL	CL74	53350	WORD			53604	2	RW	Analogue output AOL1 phase shift	0 ... 90	27	Deg
CL	CL75	53351	WORD			53605	2	RW	Analogue output AOL2 phase shift	0 ... 90	27	Deg
CL	CL76	53352	WORD			53606	0	RW	Analogue output TCL1 pulse time	5 ... 40	10	num (1 unit = 69.4 µsec)
CL	CL77	53353	WORD			53607	2	RW	Analogue output AOL1 pulse time	5 ... 40	10	num (1 unit = 69.4 µsec)
CL	CL78	53354	WORD			53608	2	RW	Analogue output AOL2 pulse time	5 ... 40	10	num (1 unit = 69.4 µsec)
CE	CE00	53792	WORD			53615	2	RW	Type of analogue input AIE1 <ul style="list-style-type: none"> 0= Probe not configured 1= DI 2 = NTC 	0 ... 2	0	num
CE	CE01	53793	WORD			53616	2	RW	Type of analogue input AIE2 See CE00	0 ... 2	0	num
CE	CE02	53794	WORD			53617	2	RW	Type of analogue input AIE3 <ul style="list-style-type: none"> 0 = Probe not configured 1 = DI 2 = NTC 3 = 4..20mA 4 = 0-10V 5 = 0-5V 6 = 0-1V 7 = 0..20mA 	0 ... 7	0	num
CE	CE03	53795	WORD			53618	2	RW	Type of analogue input AIE4 See CE02	0 ... 7	0	num
CE	CE04	53796	WORD			53619	2	RW	Type of analogue input AIE5 See CE00	0 ... 2	0	num
CE	CE10	15893	WORD	Y	-1	53620	1	RW	Analogue input AIE3 fullscale value	CE11 ... 999	500	°C/Bar
CE	CE11	15899	WORD	Y	-1	53621	1	RW	Analogue input AIE3 start of scale value	-500 ... CE10	0	°C/Bar

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	EXP	VIS PAR ADDRESS	VIS PAR VALUE	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
CE	CE12	15894	WORD	Y	-1	53622	1	RW	Analogue input AIE4 fullscale value	CE13 ... 999	500	°C/Bar
CE	CE13	15900	WORD	Y	-1	53623	1	RW	Analogue input AIE4 start of scale value	-500 ... CE12	0	°C/Bar
CE	CE20	53822	WORD	Y	-1	53624	1	RW	Analogue input AIE1 differential	-120 ... 120	0	°C
CE	CE21	53823	WORD	Y	-1	53625	1	RW	Analogue input AIE2 differential	-120 ... 120	0	°C
CE	CE22	53824	WORD	Y	-1	53626	1	RW	Analogue input AIE3 differential	-120 ... 120	0	°C/Bar
CE	CE23	53825	WORD	Y	-1	53627	1	RW	Analogue input AIE4 differential	-120 ... 120	0	°C/Bar
CE	CE24	53826	WORD	Y	-1	53628	1	RW	Analogue input AIE5 differential	-120 ... 120	0	°C
CE	CE60	53832	WORD			53629	2	RW	Type of analogue output AOE5 <ul style="list-style-type: none"> 0 = 4-20mA 1 = 0-20mA 	0 ... 1	0	num
CE	CE70	53834	WORD			53630	0	RW	Enable analogue output TCE1 <ul style="list-style-type: none"> 0 = SE655xx <i>models</i> 1 = SE646xx – <i>models</i> see CE73 – CE76 	0 ... 1	1	num
CE	CE71	53835	WORD			53631	2	RW	Enable analogue output AOE1 <ul style="list-style-type: none"> 0 = Output configured as digital – see CE96 1 = output configured as <i>Triac</i> – see CE74 – CE77 	0 ... 1	0	num
CE	CE72	53836	WORD			53632	2	RW	Enable analogue output AOE2 <ul style="list-style-type: none"> 0 = Output configured as digital – see CE97 1 = output configured as <i>Triac</i> – see CE75 – CE78 	0 ... 1	0	num
CE	CE73	53837	WORD			53633	0	RW	Analogue output TCE1 phase shift	0 ... 90	27	Deg
CE	CE74	53838	WORD			53634	2	RW	Analogue output AOE1 phase shift	0 ... 90	27	Deg
CE	CE75	53839	WORD			53635	2	RW	Analogue output AOE2 phase shift	0 ... 90	27	Deg
CE	CE76	53840	WORD			53636	0	RW	Analogue output TCE1 pulse time	5 ... 40	10	69 µsec
CE	CE77	53841	WORD			53637	2	RW	Analogue output AOE1 pulse time	5 ... 40	10	69 µsec
CE	CE78	53842	WORD			53638	2	RW	Analogue output AOE2 pulse time	5 ... 40	10	69 µsec
Cr	Cr00	53760	WORD			53609	2	RW	Type of local analogue input Air1 <ul style="list-style-type: none"> 0= Probe not configured 1 = Not used 2 = NTC 	0 ... 2	0	num
Cr	Cr01	53761	WORD			53610	2	RW	Type of local analogue input AIR2 <ul style="list-style-type: none"> 0= Probe not configured 1= DI 2 = NTC 3 = 4..20mA 4..6 = Not used 7 = 0..20mA 	0 ... 7	0	num

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	EXP	VIS PAR ADDRESS	VIS PAR VALUE	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
Cr	Cr10	15874	WORD	Y	-1	53611	1	RW	Local analogue input AIR2 fullscale value	Cr11 ... 999	0	num
Cr	Cr11	15876	WORD	Y	-1	53612	1	RW	Local analogue input AIR2 start of scale value	-999 ... Cr10	0	num
Cr	Cr20	53770	WORD	Y	-1	53613	1	RW	Local analogue input AIR1 differential	-12.0 ... 12.0	0.0	°C
Cr	Cr21	53771	WORD	Y	-1	53614	1	RW	Local analogue input AIR2 differential	-12.0 ... 12.0	0.0	°C/Bar
CF	CF01	53265	WORD			53639	2	RW	Select COM1 protocol Select COM1 (<i>TTL</i>) communication channel protocol: 0 = Eliwell; 1 = Modbus Note: <ul style="list-style-type: none"> If CF01=0 parameters CF20/CF21 should be configured. If CF01=1 parameters CF30/CF31/CF32 should be configured. 	0 ... 1	1	num
CF	CF20	53272	WORD			53640	1	RW	Eliwell protocol controller address CF20= device index in family (values from 0 to 14) CF21 = device family (values valid from 0 to 14) The pair of values CF20 and CF21 represent the device's network address and is indicated as "FF.DD" (where FF=CF21 and DD=CF20).	0 ... 14	0	num
CF	CF21	53273	WORD			53641	1	RW	Eliwell protocol controller family See CF21	0 ... 14	0	num
CF	CF30	53274	WORD			53642	3	RW	Modbus protocol controller address Note: 0 (zero) is not included.	1 ... 255	1	num
CF	CF31	53275	WORD			53643	3	RW	Modbus protocol Baudrate <ul style="list-style-type: none"> 0=not used 1= not used 2=not used 3=9600 baud 4=19200 baud 5=38400 baud 6=57600 baud 7=115200 baud 	0 ... 7	3	num
CF	CF32	53276	WORD			53644	3	RW	Modbus protocol parity <ul style="list-style-type: none"> 1= EVEN 2= NONE 3= ODD 	1 ... 3	1	num
CF	CF43	//	//	//	//	//	//	//	Firmware screen (Mask)	0 ... 999	412	num
CF	CF44	//	//	//	//	//	//	//	firmware release	0 ... 999	//	num
CF	CF50	53456	WORD			53645	0	RW	RTC present 0= RTC not present; 1 = RTC present	0 ... 1	0	num
CF	CF60	15639	WORD			53646	3	RW	Client code 1 Parameter for exclusive use of the customer/user. The client	0 ... 999	0	num

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	EXP	VIS PAR ADDRESS	VIS PAR VALUE	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
									can assign these parameters values that e.g. identify the type and/or model of the system, and its configuration etc.			
CF	CF61	15640	WORD			53647	3	RW	Client code 2 See CF60	0 ... 999	0	num
UI	UI26	15715	WORD			53648	2	RW	Key hold time to enable function	0 ... 999	350	4ms
UI	UI27	15744	WORD			53649	1	RW	Installation password When enabled (value other than zero), constitutes the password for access to parameters.	0 ... 255	1	num
UI	UI28	15745	WORD			53650	2	RW	Manufacturer password When enabled (value other than zero), constitutes the password for access to parameters.	0 ... 255	2	num

7.1.2 Folder visibility table

LABEL	ADDRESS	R/W	DESCRIPTION	DATA SIZE	RANGE	VIS. PAR VALUE	U.M.
_VisCarStati_Ai	53520	RW	Ai <i>folder</i> visibility	WORD	0 ... 3	3	num
VisCarStati_di	53521	RW	Visibility of <i>folder</i>	WORD	0 ... 3	3	num
_VisCarStati_AO	53522	RW	AO <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarStati_dO	53523	RW	dO <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarProgPar	53525	RW	PAr <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarFnC	53526	RW	FnC <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarProgPASS	53527	RW	PASS <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarPrCL	53578	RW	Par\CL <i>folder</i> visibility	WORD	0 ... 3	1	num
_VisCarPrCr	53579	RW	Par\Cr <i>folder</i> visibility	WORD	0 ... 3	1	num
_VisCarPrCE	53580	RW	Par\CE <i>folder</i> visibility	WORD	0 ... 3	1	num
_VisCarPrCF	53581	RW	Par\CF <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarPrUi	53582	RW	Par\Ui <i>folder</i> visibility	WORD	0 ... 3	1	num
_VisCarCC	53584	RW	FnC\CC <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarCC\UL	53651	RW	FnC\CC\UL <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarCC\dL	53652	RW	FnC\CC\dL <i>folder</i> visibility	WORD	0 ... 3	3	num
_VisCarCC\Fr	53653	RW	FnC\CC\Fr <i>folder</i> visibility	WORD	0 ... 3	3	num

7.1.3 Client Table

CONTENTS	FOLDER	LABEL	ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	RANGE	DEFAULT	EXP	U.M.
1	AI	LocalAIInput[0]	8336	R	Analogue input AIL1	WORD	Y	-500 ... 999	0	-1	°C
2	AI	LocalAIInput[1]	8337	R	Analogue input AIL2	WORD	Y	-500 ... 999	0	-1	°C
3	AI	LocalAIInput[2]	8338	R	Analogue input AIL3	WORD	Y	-500 ... 999	0	-1	°C/Bar
4	AI	LocalAIInput[3]	8339	R	Analogue input AIL4	WORD	Y	-500 ... 999	0	-1	°C/Bar
5	AI	LocalAIInput[4]	8340	R	Analogue input AIL5	WORD	Y	-500 ... 999	0	-1	°C
6	DI	LocalDigInput DIL1	8192	R	Digital input DIL1 status	WORD		0 ... 1	0		num
7	DI	LocalDigInput DIL2	8193	R	Digital input DIL2 status	WORD		0 ... 1	0		num
8	DI	LocalDigInput DIL3	8194	R	Digital input DIL3 status	WORD		0 ... 1	0		num
9	DI	LocalDigInput DIL4	8195	R	Digital input DIL4 status	WORD		0 ... 1	0		num
10	DI	LocalDigInput DIL5	8196	R	Digital input DIL5 status	WORD		0 ... 1	0		num
11	DI	LocalDigInput DIL6	8197	R	Digital input DIL6 status	WORD		0 ... 1	0		num
13	DO	LocalDigOutput DOL1	8528	R	Digital output DOL1	WORD		0 ... 1	0		num
14	DO	LocalDigOutput DOL2	8529	R	Digital output DOL2	WORD		0 ... 1	0		num
15	DO	LocalDigOutput DOL3	8530	R	Digital output DOL3	WORD		0 ... 1	0		num
16	DO	LocalDigOutput DOL4	8531	R	Digital output DOL4	WORD		0 ... 1	0		num
17	DO	LocalDigOutput DOL5	8532	R	Digital output DOL5	WORD		0 ... 1	0		num
18	DO	LocalDigOutput DOL6	8533	R	Digital output DOL6	WORD		0 ... 1	0		num
19	AO	LocalDigOutput AOL1	8449	R	Digital output AOL1	WORD		0 ... 1	0		num
20	AO	LocalDigOutput AOL2	8450	R	Digital output AOL2	WORD		0 ... 1	0		num
21	AO	Analog.Out TC1	8448	R	Analogue output TCL1	WORD	Y	0 ... 100	0		num
22	AO	Analog.Out AOL1	8449	R	Analogue output AOL1	WORD	Y	0 ... 100	0		num
23	AO	Analog.Out AOL2	8450	R	Analogue output AOL2	WORD	Y	0 ... 100	0		num
24	AO	Analog.Out ALO3	8451	R	Analogue output AOL3	WORD	Y	0 ... 999	0	-1	num
25	AO	Analog.Out AOL4	8452	R	Analogue output AOL4	WORD	Y	0 ... 999	0	-1	num
26	AO	Analog.Out AOL5	8453	R	Analogue output AOL5	WORD	Y	0 ... 999	0	-1	num
27	AI	ExtAIInput[0]	8352	R	Analogue input AIE1	WORD	Y	-500 ... 999	0	-1	°C
28	AI	ExtAIInput[1]	8353	R	Analogue input AIE2	WORD	Y	-500 ... 999	0	-1	°C

CONTENTS	FOLDER	LABEL	ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	RANGE	DEFAULT	EXP	U.M.
29	AI	ExtAIInput[2]	8354	R	Analogue input AIE3	WORD	Y	-500 ... 999	0	-1	°C/Bar
30	AI	ExtAIInput[3]	8355	R	Analogue input AIE4	WORD	Y	-500 ... 999	0	-1	°C/Bar
31	AI	ExtAIInput[4]	8356	R	Analogue input AIE5	WORD	Y	-500 ... 999	0	-1	°C
32	DI	ExtDigInput DIL1	8224	R	Digital input DIE1 status	WORD		0 ... 1	0		num
33	DI	ExtDigInput DIL2	8225	R	Digital input DIE2 status	WORD		0 ... 1	0		num
34	DI	ExtDigInput DIL3	8226	R	Digital input DIE3 status	WORD		0 ... 1	0		num
35	DI	ExtDigInput DIL4	8227	R	Digital input DIE4 status	WORD		0 ... 1	0		num
36	DI	ExtDigInput DIL5	8228	R	Digital input DIE5 status	WORD		0 ... 1	0		num
37	DI	ExtDigInput DIL6	8229	R	Digital input DIE6 status	WORD		0 ... 1	0		num
39	DO	ExtDigOutput DOL1	8544	R	Digital output DOE1	WORD		0 ... 1	0		num
40	DO	ExtDigOutput DOL2	8545	R	Digital output DOE2	WORD		0 ... 1	0		num
41	DO	ExtDigOutput DOL3	8546	R	Digital output DOE3	WORD		0 ... 1	0		num
42	DO	ExtDigOutput DOL4	8547	R	Digital output DOE4	WORD		0 ... 1	0		num
43	DO	ExtDigOutput DOL5	8548	R	Digital output DOE5	WORD		0 ... 1	0		num
44	DO	ExtDigOutput DOL6	8549	R	Digital output DOE6	WORD		0 ... 1	0		num
45	AO	ExtDigOutput AOE1	8465	R	Digital output AOE1	WORD		0 ... 1	0		num
46	AO	ExtDigOutput AOE2	8466	R	Digital output AOE2	WORD		0 ... 1	0		num
47	AO	Analog.Out TCE1	8464	R	Analogue output TCE1	WORD	Y	0 ... 100	0		num
48	AO	Analog.Out AOE1	8465	R	Analogue output AOE1	WORD	Y	0 ... 100	0		num
49	AO	Analog.Out AOE2	8466	R	Analogue output AOE2	WORD	Y	0 ... 100	0		num
50	AO	Analog.Out AOE3	8467	R	Analogue output AOE3	WORD	Y	0 ... 999	0	-1	num
51	AO	Analog.Out AOE4	8468	R	Analogue output AOE4	WORD	Y	0 ... 999	0	-1	num
52	AO	Analog.Out AOE5	8469	R	Analogue output AOE5	WORD	Y	0 ... 999	0	-1	num
53	AI	RemAIInput[0]	8432	R	Analogue input AIr1	WORD	Y	-500 ... 999	0	-1	°C
54	AI	RemAIInput[1]	8433	R	Analogue input AIr2	WORD	Y	-500 ... 999	0	-1	°C/Bar
55	alarm	Er45	NA	R	Clock faulty alarm	WORD		0 ... 1	0		flag
56	alarm	Er46	NA	R	Time loss alarm	WORD		0 ... 1	0		flag

Note: NA not accessible

8 FUNCTIONS (FOLDER FNC)


For a full description of MFK functioning, please refer to the relevant **Application Notes MFK cod.9IS24233 EN-IT**

The Multi Function Key (abbreviation MFK) is an accessory that can be connected to the FREE Smart (target) serial port to make a quick programming of :

- Target's parameters (upload and download of a parameter map to/from one or more target/s of the same type)
- Target's BIOS
- [FREE Studio's](#) IEC applications

Connection of MFK

To connect MFK to FREE the **YELLOW** cable is used.



MFK → FREE Smart	MFK ← FREE Smart
Parameters	Parameters
BIOS	-
IEC	-



To connect MFK to DMI the **BLU** cable is used.

DMI+PC → MFK	DMI+PC ← MFK
BIOS	-
IEC	-

9.1 General description

The *FREE Studio* development tool makes it possible to quickly and accurately create and customize new programs for all types of application. It is especially recommended for applications in the HVAC/R sector. The use of several different programming languages, in accordance with IEC61131-3 (industrial control programming standard) means new algorithms or entire programs can be developed independently, downloadable in free smart modules via PC or multi-function key with the utmost confidentiality, thanks to the appropriate security safeguards.

9.2 Components

All basic *components* and *accessories* are described below.

9.2.1 FREE Studio software component

The *Free Studio* software application has a graphic interface and its functions will be illustrated in this manual. *FREE Studio* consists of two applications

- *FREE Studio* Application, the software developer part, to create and manage libraries, applications and diagnostics.
- *FREE Studio* Device, the dedicated user part, to manage previously developed applications, upload/download applications, and modify device parameters from a serial port.

9.2.2 DM Interface (DMI) component

USB/*TTL* DMI 100-3 MANUFACTURER hardware interface, to be used in association with the software package, allows:

- The use of the software itself.
- Connection to device/s for controlling it/them.
- Connection to *Multi Function Key component*.

PLEASE NOTE: supply FREE Smart ONLY through DMI when downloading BIOS parameters and application in the FREE Smart device

9.2.3 Multi Function Key Component

This is a memory support, which allows you to:

- Update the device's parameter values.
- Updating the device's firmware.
- Download the parameter values from the device.

9.2.4 Connection cables

- Yellow cable, see 9IS42020 DMI – *FREE Studio* instructions for advice on use.
- Blue cable, see 9IS42020 DMI – *FREE Studio* instructions for advice on use.
- USB-A/A 2m extension lead.

10 MONITORING

The *TTL* serial - referred to also as COM1 – can be used to configure the device, parameters, states, and variables using the Modbus protocol.

Study the following tables:

Parameter.	Description	value	
		0	1
CF01	Select COM1 (<i>TTL</i>) protocol	Eliwell	Modbus

If CF01=0, the following parameters should be configured:

Parameter.	Description	Range
CF20	Eliwell protocol controller address	0...14
CF21	Eliwell protocol controller family	

Parameter.	Description	Range
CF30	Modbus protocol controller address	1...255
Parameter.	Description	Values
CF31	Modbus protocol Baudrate	<ul style="list-style-type: none"> • 0= not used • 1= not used • 2= not used • 3=9600 baud • 4=19200 baud • 5=38400 baud • 6=57600 baud • 7=115200 baud

10.1 Configuration with Modbus RTU

Modbus is a client/server protocol for communication between network-connected devices.

Modbus devices communicate using a master-slave technique in which a single device (the master) can send messages. All other devices in the network (slaves) respond by returning the data required to the master or executing the action indicated in the message received. A slave is defined as a device connected to a network that processes information and sends the results to a master using the Modbus protocol.

The master can send messages to individual slaves or to the entire network (broadcast) whilst slaves can only reply to messages received individually from the master.

The Modbus standard used by Eliwell uses RTU coding for data transmission.

10.1.1 Data format (RTU)

The data coding model used defines the structure of messages sent to the network and the way in which the information is decoded. The type of coding selected is generally based on specific parameters (baud rate, parity, etc)*** and some devices only support specific code *models*. However, the same model must be used for all devices connected to a Modbus network.

The protocol used the RTU binary method with the following bytes:
8 bits for data, even parity bit (not configurable), 1 stop bit.


***configured with parameters **CF30, CF31 – see table at start of paragraph.**

The device is fully configurable via parameter settings.

They can be modified with:

- The instrument's keypad.
- Multi Function key.
- By sending data via the Modbus protocol straight to individual instruments, or via broadcast, using the address 0 (broadcast).

The connection diagram when using Modbus is shown below.



Device / Bus Adapter connection	5-wire <i>TTL</i> cable (30cm) in length (other measurements/lengths available)
Bus Adapter	BA150
Bus Adapter / Interface connection	RS485 cable shielded and twisted (example: Belden model 8762 cable)

10.1.2 Modbus commands available and data areas

The commands implemented are:

Modbus command	Description of command
3	Read multiple registers on Client side
16	Write multiple registers on Client side
43	Read device ID
	DESCRIPTION Manufacturer ID Model ID Version ID

Length restrictions

Maximum length in bytes of messages sent to device	30 BYTES
Maximum length in bytes of messages received by device	30 BYTES

Variables:

See Parameters chapter (PAR), [Client table](#).

10.2 Configuration of device address

The Device Number in a ModBus message is defined by the parameter **CF30 – see table at beginning of this section**. The address 0 is used for broadcast messages that all slaves recognize. Slaves do not reply to broadcast messages.

10.2.1 Configuration of parameter addresses

The list of addresses is given in the Parameters chapter under the section headed "Parameters Table / ADDRESS column visibility (parameters addresses) and [VIS PAR ADDRESS](#) (addresses visibility parameters).

10.2.2 Configuration of variable / state addresses

The list of addresses is given in the Parameters chapter, under the section headed [Client Table](#) ADDRESS column.

11 MODELS AND ACCESSORIES

11.1 Models

11.1.1 Smart models

Model	Digital outputs (*)	TRIAC Outputs	O.C. : PWM Outputs (**)	Analogue outputs (**)	Digital inputs (§)	Analogue Inputs (**)	O.C. Outputs
SMx4500	4	-	2 O.C. : PPM	3	2	5	-
SMx3600	3	2	1	3	6	5	2
SMx4600	4	1	2	3	6	5	1
SMx5500	5	-	2	3	2(§§)	5	1

11.1.2 Expansions

Model	Digital outputs	Analogue Output	Analogue outputs O.C.: PWM/PPM	Analogue outputs (**)	Digital Inputs	Analogue Inputs	Digital Output O.C.
SE632	3	-	2	-	6	3	1
SE646	4	1	2	3	6	5	1
SE655	5	-	2	3	6	5	1
SME4500	5	-	2 O.C.: PPM	3	2(§§)	5	-

TTL supplied as standard

(*) high voltage

(**) low voltage (SELV: SAFETY EXTRA LOW VOLTAGE)

(§) no voltage

(§§) DI alternatively to O.C.:PPM

SELV: SAFETY EXTRA LOW VOLTAGE

O.C. Open Collector

PWM Pulse Width Modulation

PPM Pulse Position Modulation

/C indicates the presence of the RTC - Real Time Clock

/S RS485 Serial on board

For details about 4600 [models](#) availability, contact the Eliwell Sales Department.










11.1.3 Terminals







Model	Code	Mounting	Dimensions	Display	Analogue Inputs Safe voltage (SELV)	Power supply
SKP10		panel	74x32x30mm	LED / 4 digit	-	From base
SKW22		wall	137x96.5x31.3mm	LCD	1 onboard NTC 1 V/I configurable input	12V~ from base
SKW22L		wall	137x96.5x31.3mm	LCD backlit	1 onboard NTC 1 configurable V/I input	12V~ from base
SKP22		panel (*)	160x96x10mm	LCD	1 input NTC 1 input NTC/DI/4...20mA configurable	from base
SKP22L		panel (*)	160x96x10mm	LCD backlit		from base






(*) Contact the Eliwell Sales Office for wall-mounting [accessories](#).

11.2 Accessories

Note: the photos are intended to show the [accessories](#) and are for indication purposes only. The dimensions shown in the figures are not to scale.

	Name	Code	Description	Documentation / Notes	
Converters		SAR0RA00X701	USB/485 MINI KIT Converter + USB cable	<i>/S models</i>	
Transformer		TF411205	230V~/12V 6VA (protected) (*) <i>transformer</i>		
		TF411210	230V~/12V 11VA (protected) <i>transformer</i>		
Multi Function key		MFK100T000000	Programming key to upload/download parameters and applications		
EXP11 expansion		MW320100	230V 10A expansion module with base fitted to DIN rail		
Cables		COLV0000E0100	Cables (connector + 1m cables) to connect inputs and outputs safe voltage inputs and outputs (SELV).	4500 <i>models</i> excluded	
		COLV0000035100	RS-485 serial port wiring		
		COLV000042100	Smart – AO3-4-5 CABLES (connector + 1m cables)		
EMC filter		FT111201	LC filter, network filter, recommended for applications with fan speed modulation.		
Temperature probes	 (!) (?)	SN691150	NTC 103AT 1.5m probe, (plastic cap, 2-wire cable);	Cable Double insulation	
		SN9DAE11502C6	Sonda Pt1000 6X20 1.5mt IP68		4500 <i>models</i> only
		SN9DED11502C6	Sonda Pt1000 5X20 1.5mt IP68		4500 <i>models</i> only
		SN8DED11502C0	NTC103AT 1,5mt IP 68 5x20 -50+110°C		
		SN8DED13002C0	NTC103AT 3,0mt IP 68 5x20 -50+110°C		
		SN8DAE11502C0	NTC103AT 1,5mt IP 68 6x20 -50+110°C		
		SN8DAE13002C0	NTC103AT 3,0mt IP 68 6x20 -50+110°C		
Ratiometric transducers		TD400010	EWPA 010 R 0/5V 0/10BAR ratiometric transducer Female connector	Include 2mt cable packard IP67	
		TD400030	EWPA 030 R 0/5V 0/30BAR ratiometric transducer Female connector		
		TD400050	EWPA 050 R 0/5V 0/50BAR ratiometric transducer Female connector		

	Name	Code	Description		Documentation / Notes
Pressure transducers		(1)	Male TD220050° TD240050* TD220007° TD240007*	Female TD320050° TD340050* TD320007° TD340007*	EWPA050 4...20mA/0..50bar IP54° / IP67* EWPA007 4...20mA/-0.5...7bar IP54° / IP67* Instruction sheet 9IS64173 EWPA EN-IT-ES-DE-FR-RU
Pressure switches		(1)	HR <i>range</i> (automatic reset) - minimum 100,000 ON/OFF cycles available		
		(1)	HL <i>range</i> (manual reset) - minimum 6,000 ON/OFF cycles		
		(1)	HC <i>range</i> (automatic reset) - minimum 250,000 ON/OFF cycles		
Fan modules		For codes See instruction sheet (1)	CFS FAN MODULES Single-phase speed regulators for currents of 2A to 9A		Instruction sheet 8FI40014 CFS - Fan Speed Modules GB-I-E-D-F
		MW991300	CF-REL FAN MODULE 6A 230V relay		Instruction sheet 8FI40014 CFS - Fan Speed Modules GB-I-E-D-F
		MW991012	CFS05 TANDEM FAN MODULE <i>TRIAC</i> 5+5A 230V		Instruction sheet 8FI40016 CFS05 - Fan Speed Module GB-I-E-D-F
		Contact Eliwell Sales Department	THREE-PHASE FAN REGULATOR Contact Eliwell Sales Department		Contact Eliwell Sales Department
Interface modules		DM1003002000	DM100-3 Manufacturer		

	Name	Code	Description	Documentation / Notes
Connectivity		BA11250N3700	Bus Adapter 130 TTL RS485 TTL/RS-485 communication interface 12 V aux. output for power supply to device. TTL cable, L = 1 m (2)	Instruction sheet 9IS43084 BusAdapter 130-150-350 GB-I-E-D-F
		BA10000R3700	Bus Adapter 150 TTL RS485 TTL/RS-485 communication interface TTL cable, L = 1 m (2)	
		BARF0TS00NH00 (1)	RadioAdapter TTL/WIRELESS 802.15.4	Instruction sheet 8FI40023 RadioAdapter GB-I-E-D-F Manual 9MAX0010 RadioAdapter GB-I-E-D-F
		WA0ET00X700	WebAdapter	Instruction sheet 9IS44065 WebAdapter GB-I-E-D-F-RUS manual 8MA00202 WebAdapter X = 0 IT; 1 EN; 2 FR; 3 ES; 5 DE; A RU
		WA0WF00X700	WebAdapter Wi-Fi	
Software Tools		Contact Eliwell Sales Department	Studio	Contact Eliwell Sales Department
Demo Case		VAL00031K	Demo case Smart	

(1) Various items available. Contact the Sales Department.

(2) Various lengths can be requested.

GENERAL NOTES:

- COHV and COLV cabling are not required if they are made by the manufacturer.
- Connection of terminal via 3-way cables with no optional modules.
- Eliwell can also supply a variety of different NTC probes depending on the cable type (PVC or silicon) and length.

A	
Access to folders - menu structure.....	29
Accessories.....	52
Alarm Display (AL)	31
Analogue inputs.....	33
Analogue inputs: table.....	33
Analogue Inputs-Probes.....	10
Analogue output TC1 - AO1 AO2	35
Analogue outputs.....	34
B	
BIOS Parameters / visibility table.....	37
C	
Client Table.....	43
Components.....	47
Configuration of device address.....	49
Configuration of parameter addresses.....	49
Configuration of variable / state addresses.....	49
CONFIGURATION PHYSICAL I/O (FOLDER PAR/CL..CR).....	33
Configuration with Modbus RTU.....	48
Connection cables.....	47
Connection of MFK.....	46
Cross references	4
D	
Data format (RTU).....	48
Description of keys – combined action	27
Digital Inputs.....	34
Digital outputs.....	34
Disclaimer.....	26
Display.....	28
Display Inputs/Outputs (AiL, diL, tCL1/AOL, dOL)	30
DM Interface (DMI) component.....	47
E	
ELECTRICAL CONNECTIONS.....	10
Entering a password (Par/PASS folder).....	32
Example of AO1 / AO2 connection.....	18
Example of AO3 - AO4/A05 connection.....	18
Example of connection of high voltage outputs.....	19
Example of DO5 connection.....	19
Example of low voltage input/output connection.....	17
Example of NTC/DI input connection.....	18
Example of Smart SMP→ SE6xx connection.....	20
Example of SMC – SE6xx – SKP 10 – LCD terminal connection.....	22
Example of SMC – SKP 10 connection.....	20
Example of SMD/SMC → SE6xx connection.....	20
EXP.....	37
Expansions.....	50
F	
First switch on.....	29
Folder visibility table	42
Free Smart analogue inputs.....	33
FREE STUDIO.....	47
FREE Studio software component.....	47
FUNCTIONS (FOLDER FNC).....	46
Functions (Par/FnC folder).....	32
G	
General description.....	4; 47
General specifications.....	23
General warnings	10
H	
Highlighting icons:.....	4
I	
I/O features	23
Improper Use	26
INTRODUCTION.....	4
K	
Keys.....	27
L	
LAN	11
LEDs.....	28
LEDs and Display.....	28
M	
Main functions of hardware:.....	6
Mechanical dimensions.....	9; 25
MECHANICAL INSTALLATION	7
Mechanical specifications.....	25
Modbus commands available and data areas.....	49
Models.....	50
MODELS AND ACCESSORIES.....	50
Models and Features.....	6
MONITORING.....	48
Multi Function Key Component.....	47
N	
Network connection examples.....	20
P	
Parameters (folder PAR)	31
PARAMETERS (PAR).....	36
Parameters / visibility table, folder visibility table and client table.....	37
Permitted use.....	26
Power supply - High voltage inputs (relay).....	10
Pressure probes.....	10
Programming menu.....	31
R	
References	4
S	
SE6xx analogue inputs.....	33
SE6xx SME expansion analogue inputs.....	33
SELV analogue output AO3-4-5	35
Serial connections.....	11
Serials.....	25
Setting the clock (CL).....	30

<i>SKW SKP analogue inputs</i>	33	<i>Terminals</i>	51
<i>SKW SKP terminal analogue inputs</i>	33	Transformer	25
SKW22(L), panel-mounted LCD terminal	22	<i>TRIAC</i>	10
<i>SKW22(L), wall-mounted LCD terminal</i>	21	<i>TTL</i>	11
Smart models	50	U	
<i>Specifications:</i>	5	<i>USER INTERFACE (FOLDER PAR/UI)</i>	27
T		W	
<i>TECHNICAL DATA</i>	23	<i>Wiring diagrams</i>	12
<i>Temperature probes</i>	10		



Eliwell Controls S.r.l.

Via dell' Industria, 15 Zona Industriale Paludi
32010 Pieve d' Alpago (BL) Italy
Telephone +39 0437 986 111
Facsimile +39 0437 989 066

Sales:

+39 0437 986 100 (Italy)
+39 0437 986 200 (other countries)
saleseliwell@invensys.com

Technical helpline:

+39 0437 986 250
E-mail eliwell.freeway@invensys.com

www.eliwell.it

