

LKD

Detection and indication of refrigerant leaks



MANAGEMENT AND MONITORING



The state-of-the-art LKD gas sensors can detect the leak of a wide range of gases (R134a, R404a, NH3, R290, R600a and CO2).

**USER
MANUAL**



SUMMARY



1. INTRODUCTION	4
1.1 GENERAL DESCRIPTION	4
1.2 TECHNICAL DATA	4
1.3 REGULATIONS	5
1.4 TEST / FUNCTION INSTRUCTIONS	5
1.5 ANNUAL TEST	5
2. MECHANICAL INSTALLATION	6
2.1 WARNINGS	6
2.2 MOUNTING OF IP41 MODEL	6
2.3 MOUNTING OF IP66 MODEL	7
3. INSTALLATION / MAINTENANCE	8
3.1 INSTALLATION INSTRUCTIONS	8
3.2 LOCATION INSTRUCTIONS	8
3.2.1 LOCATION OF SENSORS	8
3.2.2 MACHINERY ROOMS	9
3.2.3 REFRIGERATED SPACES	9
3.2.4 CHILLERS	9
3.2.5 AIR CONDITIONING - DIRECT SYSTEMS VRF/VRV	10
3.3 TYPICAL SETTINGS	10
3.4 OPERATING INSTRUCTION	10
3.5 FUNCTIONS CUSTOMIZATION	10
4. CONNECTIONS AND CONFIGURATION	11
4.1 STANDARD SEMICONDUCTOR MODEL	11
4.2 MODBUS SEMICONDUCTOR MODEL	12
4.3 STANDARD INFRARED MODEL	13
4.4 MODBUS INFRARED MODEL	14
5. CONNECTION EXAMPLES	15
5.1 EXAMPLE OF STANDALONE CONNECTION	15
5.2 EXAMPLE OF NETWORK CONNECTION	15
6. FAQ	16
7. MODBUS RTU PROTOCOL	17
7.1 MODBUS RTU (REMOTE TERMINAL UNIT) PROTOCOL	17
7.2 ADDRESS	17
7.3 TECHNICAL DATA	18
7.4 FUNCTION CODES	18
7.5 REGISTER MAP	18
7.5.1 REGISTERS 1000, 1001 E 1002: GAS CONCENTRATION LEVEL	18
7.5.2 REGISTER 1003: SENSOR FULL SCALE (IN PPM)	19



7.5.3 REGISTER 1004: ALARM SETPOINT (% OF FULL SCALE).....	19
7.5.4 REGISTER 1005: SENSOR TIMER	21
7.5.5 REGISTER 1006: MODBUS ADDRESS.....	21
7.5.6 REGISTER 1007: SOFTWARE VERSION	21
7.5.7 REGISTER 2000: ALARM SETPOINT (IN PPM).....	22
7.5.8 REGISTER 2001: ALARM DELAY	23
7.5.11 REGISTER 2002: SOUNDER MUTE DURATION	24

8. WARNING **26**

8.1 CONDITIONS OF USE.....	26
8.2 LIABILITY AND RESIDUAL RISKS	26
8.3 DISCLAIMER	26

1. INTRODUCTION



TECHNICIAN USE ONLY!

This unit must be installed by a suitably qualified technician who will install this unit in accordance with these instructions and the standards set down in their particular industry/country. Suitably qualified operators of the unit should be aware of the regulations and standards set down by their industry/country for the operation of this unit. These notes are only intended as a guide and the manufacturer bears no responsibility for the installation or operation of this unit. Failure to install and operate the unit in accordance with these instructions and with industry guidelines may cause serious injury including death and the manufacturer will not be held responsible in this regard.

1.1 GENERAL DESCRIPTION

The state-of-the-art **LKD** gas sensors can detect the leak of a wide range of gases:

- R134a
- R404a
- NH₃
- R290
- R600a
- CO₂

Two models available:

- with Semiconductor (**SC**): for refrigerant gases
- with Infrared technology (**IR**): for CO₂

One of the most important features is that they can be used:

- stand-alone, thanks to a relay-activated digital output that can control a buzzer, siren, etc.
- the modbus version can be built into an Eliwell or third-party remote management system (eg. TelevisGo), thanks to an integrated modbus RS485 (n.b. only model that has it is the **CN4** connector).

The main applications are as follows:

- Compressor racks
- LT or MT cold rooms
- Refrigerated cabinets

Detection of an excessive concentration of gas (above the factory-set limit) results in the transmission of an alarm signal to the supervisor (if connected to the network) and the activation of an on-site acoustic and visual signal.

LKD gas detector ensures a prompt detection of gas leaks thus reducing the risk of machine downtime.

1.2 TECHNICAL DATA

The main technical features of LKD series are:

Model (→):	SEMICONDUCTOR R134a/R404a/NH3/R290/R600a	INFRARED CO ₂
IP rating:	IP41 (MT applications)	and IP66 (LT applications)
Dimensions/Weight:	IP41 : 86x142x53 - 180 gr.	and IP66 : 175x165x82 - 629 gr.
Power supply:	12/24V~/~ ±20% 50/60 Hz	
Power Consumption (at 12V):	153mA	136mA
Analogue outputs:	0-5V, 1-5V, 0-10V, 2-10V, 4-20mA	
Digital outputs:	1 relay a 1A/24V~/~	
Internal Buzzer:	YES	
Selectable alarm delay (see J5 and J6):	0, 1, 5, 10 min	
Connections:	1 RS485 for connection to Supervisor Modbus (depending on model)	
Typical operating range:	R134a/R404a : 0...1,000 ppm R290/R600a : 0...2,000 ppm NH3 : 0...1,000 and 0...10,000 ppm	CO₂ : 0...10,000 ppm
Temperature range:	IP41 : -20°C ... +50°C and IP66 : -40°C ... +50°C	
Humidity range:	0 ... 95% (non condensing)	
Acoustic alarm(see J3):	enabled/disabled	
Power supply display:	Green LED	
Alarm display:	Red LED	
Fault status:	1-5 V configuration: 0.5V 2-10 V configuration: 1V 4-20mA configuration: 2ma	
Fault indication:	Red LED ON - Green LED OFF	
Sensor service life:	5-8 years	8-10 years
T50 alarm threshold:	76 secs	25 secs
T90 alarm threshold:	215 secs	90 secs
Recovery time:	600 secs	210 secs



1.3 REGULATIONS


LKD gas sensors are compliant with:

- F-GAS - CE 842/2006 regulation
- UNI EN378 standard

provided they are installed by qualified technical personnel and they are checked periodically according to methods and frequency set by local regulations.

1.4 TEST / FUNCTION INSTRUCTIONS

The LKD is calibrated in the factory and does not require to be calibrated on installation.

 After installation the units should be bump tested.

Expose the sensors to test gas:

- using an Eliwell ampoule (NH₃, CO₂, etc.)
- using a test cylinder (appropriate to the installation)
- open the valve of a cigarette lighter (only for Semiconductor units) without igniting it and hold it over the vent holes on the upper right side of the LKD. The gas is heavier than air and should fall into the LKD.

This will put the system into alarm:

- The red LED will light showing the system is in alarm.
- The delay will prevent the siren sounding or relay switching for the preset delay, if delay is set.

With a bump test you can see the functions of the sensor:

- the red LED will light
- the relay and sounder will function
- the output selected (for example 0-10 V) will show the gas level.

To test the siren and or relay function, check the delay is set at zero using the header as shown on the installation diagram and expose to gas as above. You can mute the siren by removing the jumper **J3**.

 After the gas has cleared the red led, siren and relay will automatically reset.

Before testing the sensors on site the LKD must have been powered up and allowed to stabilize.

1.5 ANNUAL TEST

To comply with the requirements of EN378 and the F-GAS regulation sensors must be tested annually.

However local regulations may specify the nature and frequency of this test.

If not the recommended procedure should be followed.

Check local regulations on calibration or testing requirements.



ATTENTION!

After exposure to a substantial gas leak, sensor should be checked and replaced if necessary.



CALIBRATION: Sensor calibration is recommended every three years.



GAS SENSOR: In order to ensure a correct functioning of the unit, a replacement of the gas sensor is recommended every 6 years.

2. MECHANICAL INSTALLATION



IMPORTANT!

Always make sure the device is switched OFF before touching connections.
All operations must be carried out by QUALIFIED PERSONNEL.


2.1 WARNINGS

The mechanical mounting varies depending on the version which is being installed (IP41 or IP66).

There are no different mounting instructions for semi-conductor and IR models except for their positioning inside the room to be monitored, which depends on the specific behaviour of the monitored gas.

2.2 MOUNTING OF IP41 MODEL

The following pictures show dimensions and mounting diagram for model IP41.







2.3 MOUNTING OF IP66 MODEL

The following pictures show dimensions and mounting diagram for model IP66.

DIMENSIONS



MOUNTING



3. INSTALLATION / MAINTENANCE



3.1 INSTALLATION INSTRUCTIONS

The following steps must be followed:

1. To open the Sensor enclosure: the procedure varies depending on the model:

- IP41 model: press the fixing device on the top of the box to open it.
To close it, follow the contrary steps; don't forget to insert the cable clamp in the proper slot on the bottom of the instrument.
- IP66 model: unscrew the 4 allen screws on the top surface of the instrument.
To close it, follow the contrary steps.

2. Power supply: 12-24 V \approx /~, connect power supply cable at positions **0V** and **+V** at connector block **CN1**.

- NOTES:**
- For AC voltage (~), set jumpers J1 = ON and J2 = OFF (See wiring diagram).
 - For DC voltage (\approx), set jumpers J1 = OFF and J2 = ON (See wiring diagram).

Default factory setting is direct voltage (\approx).

Use 2 cores of a 4-core cable, low voltage alarm type (typically 7/0,2 mm²)

3. Output: depending on the type of unit used (Standard or Modbus), it is possible to set the analog output as Voltage Output (V) or Current Output (mA) by means of the jumpers.

- Standard Model: set jumpers **Jx** and **Jy** (See wiring diagram).
- Modbus Model: set jumpers **J7, J8, J9** and **J10** (See wiring diagram).

Default factory setting is mA (on Standard model) and always active (on Modbus model).

Connect the other two cores of the 4-core cable used for the power supply to terminal block **CN2** in the following positions:

- Current output 4...20mA: Connect the cores of the cable to terminals **3 (0V)** and **5 (I)** of **CN2**.
- Voltage outputs 0...5V, 0...10V, 1...5V and 2...10V: Connect the cores of the cable to terminals **3 (0V)** and **4 (V)** of **CN2**.

NOTE: You can common the two zeros and use 3 core cable if preferred.

4. Relay setpoint: The potentiometer **P1** sets the trip point for the relay and sounder using the 0-5V scale.

The measurement can be effected between Test Point **TP3 (0V)** and **TP1 (VREF)** on Standard model and **Alarm** on Modbus model). A reading of **2,5 V** corresponds to half the range (500 ppm on a scale from 0 to 1000 ppm).

Default factory setting is 50% of the range.


5. Time delay: A time delay for the operation of the relay and sounder can be selected using jumpers J5 and J6.

- J5 = OFF, J6 = OFF** : 0 minutes (no delay)
- J5 = ON, J6 = OFF** : 1 minute
- J5 = OFF, J6 = ON** : 5 minutes
- J5 = ON, J6 = ON** : 10 minutes

Default factory setting is **J5 = OFF** and **J6 = OFF**.

6. Sounder: The sounder can be disabled using jumper **J3**.

Default factory setting is option enabled.

 **NOTE:** There is a 5-minute power up delay to allow the sensor to stabilize.
This can be cancelled by momentarily shorting between either of the upper and lower pads of SW1 or SW2.

3.2 LOCATION INSTRUCTIONS

3.2.1 LOCATION OF SENSORS

Sensors must be located within the appropriate wire lengths from the central control unit (if used).

In all cases the sensor supplied is designed for maximum sensitivity to a particular gas (e.g.: R134a, NH₃, R290, etc.).

However, in certain circumstances, false alarms may be caused by the occasional presence of sufficiently high concentrations of other gaseous impurities.

If such a situation is likely to arise installers should check that sensor (s) of suitable cross sensitivity can be supplied.

Examples of situations where such abnormalities may arise include:

- Plant room maintenance activity involving solvent or paint fumes or refrigerant leaks.
- Plant rooms in fruit ripening/storage facilities because of accidental gas migration (bananas - ethylene, apples - carbon dioxide)
- Heavy localised exhaust fumes (carbon monoxide, dioxide, propane) from engine driven forklifts in confined spaces or close to sensors.

A response delay may be selected to minimise any problems that might arise.



3.2.2 MACHINERY ROOMS

There is NO ABSOLUTE RULE in determining the number of sensors and their location. However a number of simple guidelines will help to make a decision.

Sensors monitor a point as opposed to an area.



ATTENTION!

If the gas leak does not reach the sensor then no alarm will be raised.

Therefore, it is extremely important to carefully select the sensor location. Also consider ease of access for maintenance.

The size and nature of the site will help to decide which method is the most appropriate to use.

Locations requiring the most protection in a machinery or plant room would be around compressors, pressurised storage vessels, refrigerant cylinders or storage rooms or pipelines.

Most vulnerable are valves, gauges, flanges, joints (brazed or mechanical), filling or draining connections, etc.

When mechanical or natural ventilation is present mount a sensor in the airflow.

In machinery rooms where there is no discernable or strong airflow then options are:

- Point Detection, where sensors are located as near as possible to the most likely sources of leakage, such as the compressor, expansion valves, mechanical joints or cable duct trenches.
- Perimeter Detection, where sensors completely surround the area or equipment.
- With heavier than air gases such as halocarbon and hydrocarbon refrigerants such as R404A, propane, and butane sensors should be located near ground level.
- With lighter than air gas e.g. ammonia, the sensor needs to be located above the equipment to be monitored on a bracket or high on a wall within 300 mm of, or on the ceiling provided there is no possibility of a thermal layer trapped under the ceiling preventing gas reaching the sensor.
(NOTE: At very low temperatures, such as in a refrigerated cold store, ammonia gas becomes heavier than air).
- With similar density or miscible gases, such as CO₂, sensors should be mounted about head high - say 1.5m.
- Sensors should be positioned a little way back from any high-pressure parts to allow gas clouds to form. Otherwise any leakage of gas is likely to pass by in a high-speed jet and not be detected by the sensor.
- Make sure that pits, stairwells and trenches are monitored since they may fill with stagnant pockets of gas.
- If a pressure relief vent pipe is fitted to the system, it may be a requirement to mount a sensor to monitor this vent pipe. It should be positioned about 2 m above the PRV to allow gas clouds to form.
- With racks or chillers pre-fitted with refrigerant sensors, these should be mounted so as to monitor the compressors or if extract ducts are fitted the airflow in the duct may be monitored.

3.2.3 REFRIGERATED SPACES

In refrigerated spaces sensors should be located in the return airflow to the evaporators on a sidewall, below head height is preferred, or on the ceiling, not directly in front of an evaporator.

In large rooms with multiple evaporators, sensors should be mounted on the central line between 2 adjacent evaporators, as turbulence will result in airflows mixing.

3.2.4 CHILLERS

In the case of small water or air-cooled enclosed chiller units mount the sensor so as to monitor airflow to the extract fans.

With larger models also place a sensor inside the enclosure under or adjacent to the compressors.

In the case of outdoor units:

- such as enclosed air-cooled chillers or the outdoor unit for VRV/VRF systems mount the sensor so as to monitor airflow to the extract fan. With large units also place a sensor inside the enclosure under or adjacent to the compressors.

In the case of non-enclosed outdoor units:

- If there is an enclosed machinery section then locate a sensor there.
- In the case of units with enclosed compressors, mount sensors in the enclosures.
- Where you have protective or acoustic panels mount the sensor low down under the compressors where it is protected by the panels.
- With air-cooled chillers or air-cooled condensers with non-enclosed condenser sections it is difficult to effectively monitor leaks in the coil sections. With some designs it will be possible using an airflow sensor to monitor airflow to the start-up fans in the front or rear sections.
- If there is a possibility of refrigerant leaks into a duct or air-handling unit install a sensor to monitor the airflow.

Weatherproof sensors should be used for unprotected outdoor applications.



3.2.5 AIR CONDITIONING - DIRECT SYSTEMS VRF/VRV

EN378 states that at least one detector shall be installed in each occupied space being considered. Also the location of detectors shall be chosen in relation to the refrigerant.

Sensors shall be located where the refrigerant from the leak will collect. In this case refrigerants are heavier than air and detectors should have their sensors mounted low or other similar Category Class A spaces. Ceiling or other voids if not sealed are part of the occupied space.

Following a list of things to do and not to do:

DO'S	DON'TS
<ul style="list-style-type: none"> • mount the in-room sensor at less than the normal heights of the occupants (between 200-500mm off the floor) • away from draughts and heat sources like radiators etc. • avoid sources of steam 	Do not mount LKD sensors: <ul style="list-style-type: none"> • under reflective surfaces (e.g.: mirrors) • inside electrical boards • in or near bathrooms.

3.3 TYPICAL SETTINGS

An example of typical setting is:

- **Gas:** refrigerant R404A
- **Range:** 0-1000 ppm
- **Alarm setpoint:** 500 ppm

For a particular unit please refer to the gas settings shown on the rating plate.

3.4 OPERATING INSTRUCTION

- On powering up:** the sensor will sense the presence of gas after an initial warm-up delay of 5 minutes. The green LED will flash at 1 second intervals during the warmup (not for MODBUS model).
- In alarm condition:**
 - the green LED stays ON;
 - the red LED will be ON;
 - the buzzer operates (if it has not been disabled using jumper **J3** and after a delay if this option has been selected using jumpers **J5** and **J6** or using modbus command);
 - the relay output activates (after a delay if this option has been selected using jumpers **J5** and **J6** or using modbus command);
 - the voltage or current output changes proportional to gas concentration.
- Fault condition:**
 - the green LED will be OFF;
 - the red LED will be ON;
 - a voltage or current fault output will activate:
 - current fault: **2 mA** on the 4-20 mA output;
 - voltage fault: **0,5 V** on the 1-5 V output and **1,0 V** on the 2-10 V output.

3.5 FUNCTIONS CUSTOMIZATION

The functions listed below, need to be agreed with the customer, so that the system will operate as required:

- Alarm signal delay:** applicable to the acoustic alarm (buzzer) and to the relay in order to avoid false alarms. The delay is set by using jumpers **J5** and **J6**.
 - J5 = OFF, J6 = OFF :** 0 minutes (no delay)
 - J5 = ON, J6 = OFF :** 1 minute
 - J5 = OFF, J6 = ON :** 5 minutes
 - J5 = ON, J6 = ON :** 10 minutes

The default value is 0 minutes.

- Buzzer:** the units have an internal buzzer. It is possible to disable it by removing jumper **J3**. The default setting is "buzzer enabled" in compliance to EN378.
- Output:** set the requested analog output (current or voltage)


Gas detectors can activate external systems such as fans or shut down and activate sirens, warning lights or connect to most BMS, SCADA, or other control systems using one or more outputs.

- 4...20 mA, 0...5 V, 1...5 V, 0...10 V or 2...10 V.
- Relay 1A at 24 V~ or 120 V~

4. CONNECTIONS AND CONFIGURATION



4.1 STANDARD SEMICONDUCTOR MODEL




ELECTRICAL CONNECTIONS and CONFIGURATION

CN1	Power Supply J1 = ON, J2 = OFF ➔ AC : 1 = ~ , 2 = ~ (12...24 V~) J1 = OFF, J2 = ON ➔ DC : 1 = 0V, 2 = V+ (12...24 V~)																
CN2	Output signals 3 = 0V (0 Volts, ground) 4 = V (The voltage output settings are: <div style="display: inline-block; vertical-align: middle; margin-left: 20px;"> <table style="border-left: 1px solid black; border-right: 1px solid black; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;">{</td> <td style="padding: 0 5px;">Jx = OFF, Jy = OFF</td> <td style="padding: 0 5px;">➔</td> <td style="padding: 0 5px;">Voltage output = 0 ... 10V</td> </tr> <tr> <td style="padding: 0 5px;">{</td> <td style="padding: 0 5px;">Jx = ON, Jy = OFF</td> <td style="padding: 0 5px;">➔</td> <td style="padding: 0 5px;">Voltage output = 0 ... 5V</td> </tr> <tr> <td style="padding: 0 5px;">{</td> <td style="padding: 0 5px;">Jx = OFF, Jy = ON</td> <td style="padding: 0 5px;">➔</td> <td style="padding: 0 5px;">Voltage output = 2 ... 10V</td> </tr> <tr> <td style="padding: 0 5px;">{</td> <td style="padding: 0 5px;">Jx = ON, Jy = ON</td> <td style="padding: 0 5px;">➔</td> <td style="padding: 0 5px;">Voltage output = 1 ... 5V</td> </tr> </table> </div> 5 = I (Current output = 4 ... 20 mA) NOTE: Current output needs to be enabled using Jy (Jy = ON)	{	Jx = OFF, Jy = OFF	➔	Voltage output = 0 ... 10V	{	Jx = ON, Jy = OFF	➔	Voltage output = 0 ... 5V	{	Jx = OFF, Jy = ON	➔	Voltage output = 2 ... 10V	{	Jx = ON, Jy = ON	➔	Voltage output = 1 ... 5V
{	Jx = OFF, Jy = OFF	➔	Voltage output = 0 ... 10V														
{	Jx = ON, Jy = OFF	➔	Voltage output = 0 ... 5V														
{	Jx = OFF, Jy = ON	➔	Voltage output = 2 ... 10V														
{	Jx = ON, Jy = ON	➔	Voltage output = 1 ... 5V														
CN3	Relay 6 = NO (Normally Open) 7 = COM (Common) 8 = NC (Normally Closed)																
P1	Alarm Potentiometer P1 (Alarm): Adjust alarm setpoint for the sounder and relay.																
P2	ZERO Potentiometer P2 (ZERO): Adjust the zero level voltage for the output signal.																
P3	SPAN Potentiometer P3 (SPAN): Adjust output signal span.																
J1, J2	Power Supply Jumper (ON OFF) J1 = ON, J2 = OFF : Unit is set for AC power supply J1 = OFF, J2 = ON : Unit is set for DC power supply																
J3	Sounder Jumper (ON OFF) ON = Sounder enabled (Audible alarm if Setpoint reached) OFF = Sounder disabled (No audible alarms)																
J5, J6	Sounder & Relay delay Jumper (ON OFF) J5 = OFF, J6 = OFF : 0 minutes (no delay) J5 = ON, J6 = OFF : 1 minute J5 = OFF, J6 = ON : 5 minutes J5 = ON, J6 = ON : 10 minutes																
Jx, Jy	Jumper Jx and Jy (Voltage output range selection) (ON OFF) Jx = OFF, Jy = OFF ➔ Voltage output setting = 0 ... 10V Jx = ON, Jy = OFF ➔ Voltage output setting = 0 ... 5V Jx = OFF, Jy = ON ➔ Voltage output setting = 2 ... 10V Jx = ON, Jy = ON ➔ Voltage output setting = 1 ... 5V																
Jz	NOT USED																
TP1	Setpoint Voltage Test Point TP1 (VREF): Sounder and relay setpoint Voltage.																
TP2	Vs Sensor Voltage Test Point TP2 (Vs): Vs sensor voltage.																
TP3	0V Test Point TP3 (0V): Board ground plane connection.																



4.2 MODBUS SEMICONDUCTOR MODEL

CONNECTION DIAGRAM




ELECTRICAL CONNECTIONS and CONFIGURATION

CN1	Power Supply J1 = ON, J2 = OFF ➔ AC : 1 = ~ , 2 = ~ (12...24 V~) J1 = OFF, J2 = ON ➔ DC : 1 = 0V , 2 = V+ (12...24 V~)
CN2	Output signals 3 = 0V (0 Volts, ground) 4 = V (The voltage output settings are: 5 = I (Current output = 4 ... 20 mA) { J7 = ON, J8, J9, J10 = OFF ➔ Voltage output = 0 ... 5V J8 = ON, J7, J9, J10 = OFF ➔ Voltage output = 0 ... 10V J9 = ON, J7, J8, J10 = OFF ➔ Voltage output = 1 ... 5V J10 = ON, J7, J8, J9 = OFF ➔ Voltage output = 2 ... 10V
CN3	Relay 6 = NO (Normally open) • 7 = COM (Common) • 8 = NC (Normally Closed)
CN4	Modbus (RS485) 9 = GND (Ground - Isolated from 0V) • 10 = Tx/Rx+ (Non inverting Modbus Signal) • 11 = Tx/Rx- (Inverting Modbus Signal)
P1	Alarm Potentiometer P1 (Alarm) : Adjust alarm setpoint for the sounder and relay.
P2	ZERO Potentiometer P2 (ZERO) : Adjust the zero level voltage for the output signal.
P3	SPAN Potentiometer P3 (SPAN) : Adjust output signal span.
P4	4...20 mA Potentiometer P4 (4-20mA) : Adjust the 4 to 20 mA current output.
J1, J2	Power Supply Jumper (ON • OFF) J1 = ON, J2 = OFF : Unit is set for AC power supply J1 = OFF, J2 = ON : Unit is set for DC power supply
J3	Sounder Jumper (ON • OFF) ON = Sounder enabled (Audible alarm if Setpoint reached) • OFF = Sounder disabled (No audible alarms)
J4	Reset Jumper (ON • OFF) ON = Stop Unit operation • OFF = Normal functioning
J5, J6	Sounder & Relay delay Jumper (ON • OFF) J5 = OFF, J6 = OFF : 0 minutes (no delay) J5 = ON, J6 = OFF : 1 minute J5 = OFF, J6 = ON : 5 minutes J5 = ON, J6 = ON : 10 minutes
J7, J8, J9, J10	Jumper J7, J8, J9 e J10 (Voltage output range selection) (ON • OFF) Jumper J7 (Voltage output setting: 0 ... 5V) : J7 = ON, J8, J9, J10 = OFF Jumper J8 (Voltage output setting: 0 ... 10V) : J8 = ON, J7, J9, J10 = OFF Jumper J9 (Voltage output setting: 1 ... 5V) : J9 = ON, J7, J8, J10 = OFF Jumper J10 (Voltage output setting: 2 ... 10V) : J10 = ON, J7, J8, J9 = OFF
TP1	Setpoint Voltage Test Point TP1 (Alarm) : Sounder and relay setpoint Voltage.
TP2	Vs Sensor Voltage Test Point TP2 (Vs) : Vs sensor voltage.
TP3	0V Test Point TP3 (0V) : Board ground plane connection.
SW1, SW2	Address . The valid address has a range of 0 ... 247 and the value is $ADR = [SW1 + (SW2 \times 16)]$. Example: • SW1=1, SW2=0 ➔ ADR= 1 (Valid address) • SW1=1, SW2=1 ➔ ADR= 17 (Valid address) • SW1=7, SW2=F ➔ ADR= 247 (Valid address) • SW1=F, SW2=F ➔ ADR= 255 (Reserved) NOTES : 1) SW1 and SW2 are hexadecimal dial switches. 2) see full Address Table on the Modbus chapter.



4.3 STANDARD INFRARED MODEL

CONNECTION DIAGRAM




ELECTRICAL CONNECTIONS and CONFIGURATION

CN1	Power Supply J1 = ON, J2 = OFF ➔ AC : 1 = ~ , 2 = ~ (12...24 V~) J1 = OFF, J2 = ON ➔ DC : 1 = 0V , 2 = V+ (12...24 V~)												
CN2	Output signals 3 = 0V (0 Volts, ground) 4 = V (The voltage output settings are: <div style="display: flex; align-items: center; margin-left: 20px;"> <div style="font-size: 3em; margin-right: 10px;">{</div> <table style="border: none;"> <tr> <td>Jx = OFF, Jy = OFF</td> <td>➔</td> <td>Voltage output = 0 ... 10V</td> </tr> <tr> <td>Jx = ON, Jy = OFF</td> <td>➔</td> <td>Voltage output = 0 ... 5V</td> </tr> <tr> <td>Jx = OFF, Jy = ON</td> <td>➔</td> <td>Voltage output = 2 ... 10V</td> </tr> <tr> <td>Jx = ON, Jy = ON</td> <td>➔</td> <td>Voltage output = 1 ... 5V</td> </tr> </table> </div> 5 = I (Current output = 4 ... 20 mA) NOTE: Current output needs to be enabled using Jy (Jy = ON)	Jx = OFF, Jy = OFF	➔	Voltage output = 0 ... 10V	Jx = ON, Jy = OFF	➔	Voltage output = 0 ... 5V	Jx = OFF, Jy = ON	➔	Voltage output = 2 ... 10V	Jx = ON, Jy = ON	➔	Voltage output = 1 ... 5V
Jx = OFF, Jy = OFF	➔	Voltage output = 0 ... 10V											
Jx = ON, Jy = OFF	➔	Voltage output = 0 ... 5V											
Jx = OFF, Jy = ON	➔	Voltage output = 2 ... 10V											
Jx = ON, Jy = ON	➔	Voltage output = 1 ... 5V											
CN3	Relay 6 = NO (Normally Open) 7 = COM (Common) 8 = NC (Normally Closed)												
P1	Alarm Potentiometer P1 (Alarm): Adjust alarm setpoint for the sounder and relay.												
P2	ZERO Potentiometer P2 (ZERO): Adjust the zero level voltage for the output signal.												
P3	SPAN Potentiometer P3 (SPAN): Adjust output signal span.												
J1, J2	Power Supply Jumper (ON · OFF) J1 = ON, J2 = OFF : Unit is set for AC power supply J1 = OFF, J2 = ON : Unit is set for DC power supply												
J3	Sounder Jumper (ON · OFF) ON = Sounder enabled (Audible alarm if Setpoint reached) OFF = Sounder disabled (No audible alarms)												
J5, J6	Sounder & Relay delay Jumper (ON · OFF) J5 = OFF, J6 = OFF : 0 minutes (no delay) J5 = ON, J6 = OFF : 1 minute J5 = OFF, J6 = ON : 5 minutes J5 = ON, J6 = ON : 10 minutes												
Jx, Jy	Jumper Jx and Jy (Voltage output range selection) (ON · OFF) Jx = OFF, Jy = OFF ➔ Voltage output setting = 0 ... 10V Jx = ON, Jy = OFF ➔ Voltage output setting = 0 ... 5V Jx = OFF, Jy = ON ➔ Voltage output setting = 2 ... 10V Jx = ON, Jy = ON ➔ Voltage output setting = 1 ... 5V												
Jz	NOT USED												
TP1	Setpoint Voltage Test Point TP1 (VREF): Sounder and relay setpoint Voltage.												
TP2	Vs Sensor Voltage Test Point TP2 (Vs): Vs sensor voltage.												
TP3	0V Test Point TP3 (0V): Board ground plane connection.												



4.4 MODBUS INFRARED MODEL

CONNECTION DIAGRAM




ELECTRICAL CONNECTIONS and CONFIGURATION

CN1	Power Supply J1 = ON, J2 = OFF ➔ AC : 1 = ~ , 2 = ~ (12...24 V~) J1 = OFF, J2 = ON ➔ DC : 1 = 0V , 2 = V+ (12...24 V~)					
CN2	Output signals 3 = 0V (0 Volts, ground) 4 = V (The voltage output settings are: <div style="display: inline-block; vertical-align: middle; margin-left: 20px;"> <table style="border: none;"> <tr> <td style="font-size: 3em; vertical-align: middle;">{</td> <td style="padding-left: 5px;">J7 = ON, J8, J9, J10 = OFF ➔ Voltage output = 0 ... 5V</td> </tr> <tr> <td style="padding-left: 5px;">J8 = ON, J7, J9, J10 = OFF ➔ Voltage output = 0 ... 10V</td> </tr> <tr> <td style="padding-left: 5px;">J9 = ON, J7, J8, J10 = OFF ➔ Voltage output = 1 ... 5V</td> </tr> <tr> <td style="padding-left: 5px;">J10 = ON, J7, J8, J9 = OFF ➔ Voltage output = 2 ... 10V</td> </tr> </table> </div> 5 = I (Current output = 4 ... 20 mA)	{	J7 = ON, J8, J9, J10 = OFF ➔ Voltage output = 0 ... 5V	J8 = ON, J7, J9, J10 = OFF ➔ Voltage output = 0 ... 10V	J9 = ON, J7, J8, J10 = OFF ➔ Voltage output = 1 ... 5V	J10 = ON, J7, J8, J9 = OFF ➔ Voltage output = 2 ... 10V
{	J7 = ON, J8, J9, J10 = OFF ➔ Voltage output = 0 ... 5V					
J8 = ON, J7, J9, J10 = OFF ➔ Voltage output = 0 ... 10V						
J9 = ON, J7, J8, J10 = OFF ➔ Voltage output = 1 ... 5V						
J10 = ON, J7, J8, J9 = OFF ➔ Voltage output = 2 ... 10V						
CN3	Relay 6 = NO (Normally open) • 7 = COM (Common) • 8 = NC (Normally Closed)					
CN4	Modbus (RS485) 9 = GND (Ground - Isolated from 0V) • 10 = Tx/Rx+ (Non inverting Modbus Signal) • 11 = Tx/Rx- (Inverting Modbus Signal)					
P1	Alarm Potentiometer P1 (Alarm): Adjust alarm setpoint for the sounder and relay.					
P2	ZERO Potentiometer P2 (ZERO): Adjust the zero level voltage for the output signal.					
P3	SPAN Potentiometer P3 (SPAN): Adjust output signal span.					
P4	4...20 mA Potentiometer P4 (4-20mA): Adjust the 4 to 20 mA current output.					
J1, J2	Power Supply Jumper (ON OFF) J1 = ON, J2 = OFF : Unit is set for AC power supply J1 = OFF, J2 = ON : Unit is set for DC power supply					
J3	Sounder Jumper (ON OFF) ON = Sounder enabled (Audible alarm if Setpoint reached) • OFF = Sounder disabled (No audible alarms)					
J4	Reset Jumper (ON OFF) ON = Stop Unit operation • OFF = Normal functioning					
J5, J6	Sounder & Relay delay Jumper (ON OFF) J5 = OFF, J6 = OFF : 0 minutes (no delay) J5 = ON, J6 = OFF : 1 minute J5 = OFF, J6 = ON : 5 minutes J5 = ON, J6 = ON : 10 minutes					
J7, J8, J9, J10	Jumper J7, J8, J9 e J10 (Voltage output range selection) (ON OFF) Jumper J7 (Voltage output setting: 0 ... 5V) : J7 = ON, J8, J9, J10 = OFF Jumper J8 (Voltage output setting: 0 ... 10V) : J8 = ON, J7, J9, J10 = OFF Jumper J9 (Voltage output setting: 1 ... 5V) : J9 = ON, J7, J8, J10 = OFF Jumper J10 (Voltage output setting: 2 ... 10V) : J10 = ON, J7, J8, J9 = OFF					
TP1	Setpoint Voltage Test Point TP1 (Alarm): Sounder and relay setpoint Voltage.					
TP2	Vs Sensor Voltage Test Point TP2 (Vs): Vs sensor voltage.					
TP3	0V Test Point TP3 (0V): Board ground plane connection.					
SW1, SW2	Address. The valid address has a range of 0 ... 247 and the value is $ADR = [SW1 + (SW2 \times 16)]$. Example: • SW1=1, SW2=0 ➔ ADR= 1 (Valid address) • SW1=1, SW2=1 ➔ ADR= 17 (Valid address) • SW1=7, SW2=F ➔ ADR= 247 (Valid address) • SW1=F, SW2=F ➔ ADR= 255 (Reserved) NOTES: 1) SW1 and SW2 are hexadecimal dial switches. 2) see full Address Table on the Modbus chapter.					


5. CONNECTION EXAMPLES



5.1 EXAMPLE OF STANDALONE CONNECTION



5.2 EXAMPLE OF NETWORK CONNECTION



6. FAQ



Here is a list of some of the error signals which might occur:

DEFECT:	Green/Red light on sensor is not lit.
CAUSE:	<ul style="list-style-type: none">• power supply.• possible wiring fault.• LKD possibly damaged in transit.
RESOLUTION:	<ul style="list-style-type: none">• check power supply.• check wiring.• install another LKD unit to confirm the presence of a fault.
DEFECT:	Red LED light ON and green LED light OFF to indicate a fault.
CAUSE:	<ul style="list-style-type: none">• sensor element may be disconnected from board.• sensor element has been damaged or has reached end of life.
RESOLUTION:	<ul style="list-style-type: none">• check to see sensor element is properly inserted into board.• change sensor.
DEFECT:	You experience spurious alarms in the absence of a leak.
CAUSE:	Presence of sufficiently high concentrations of other gaseous impurities.
RESOLUTION:	Contact technical support for instructions and support.

7. MODBUS RTU PROTOCOL



7.1 MODBUS RTU (REMOTE TERMINAL UNIT) PROTOCOL

The **CN4** Connector (**9 = GND**, **10 = Tx/Rx+**, **11 = Tx/Rx-**) is an RS-485 port for communicating between **LKD** gas detectors and the Remote Supervision system in Modbus-RTU protocol.

The meaning of terminals is listed below:

- **Tx/Rx+** is the non-inverting data signal
- **Tx/Rx-** is the inverted data signal
- **GND** is the board ground plane.

7.2 ADDRESS

There are 256 available selections and the addresses are numbered 0 to 255 inclusive.

Addresses are selected by rotating the hexadecimal dial switches **SW1** and **SW2**.



ATTENTION!

- Values **1 to 247** are valid / usable addresses providing a unique identity for each gas detector.
- Addresses **248 to 255** and address **0** are reserved for implementing specific features.


Modbus data with a zero in the address field is received by all detectors (irrespective of the address selected by the dial switches) to enable the master device to broadcast simultaneously to all the detectors.

Switch **SW1** selects addresses 0 to 15 and switch **SW2** multiplies the address by a factor of 16.

ADDRESS	SW1	SW2	SELECTION
0	0	0	RESERVED
1	1	0	Address 1
2	2	0	Address 2
⋮	⋮	⋮	⋮
9	9	0	Address 9
10	A	0	Address 10
11	B	0	Address 11
12	C	0	Address 12
13	D	0	Address 13
14	E	0	Address 14
15	F	0	Address 15
16	0	1	Address 16
17	1	1	Address 17
⋮	⋮	⋮	⋮
246	6	F	Address 246
247	7	F	Address 247
248	8	F	RESERVED
249	9	F	RESERVED
250	A	F	RESERVED
⋮	⋮	⋮	⋮
254	E	F	Selects 9,600 Baud (bits per second)
255	F	F	Selects 19,200 Baud (bits per second)

SW1

E = 14



SW2

F = 15



ADDRESS 254 = 14 + 15 (x16)

As an example, address 254 is reserved for setting the Baud rate to 9,600 bits per second.

To choose a baud rate, select the address and reset the gas detector by shorting jumper **J4** or by cycling the power on and off. The desired Modbus address (**1...247**) can subsequently be selected.



7.3 TECHNICAL DATA

Baud Rate	9,600	19,200	bits per second (selectable using SW1 and SW2)
Start	1	1	bit
Data	8	8	bit
Parity	1	1	bit (even parity)
Stop	1	1	bit
Retry	500	500	milliseconds (<i>minimum time between retries</i>)
End of message	3.5	3.5	characters (<i>a silent of 3.5 characters indicates the end of a message, a new message can begin after this interval</i>)

7.4 FUNCTION CODES

Function codes specify the action to be performed on the data in the registers of the gas detector.

FUNCTION CODE	ACTION	REGISTERS	
01	Read Output Digital Status flags	4000	read / writable
02	Read Input Digital Status flags	3000	read only
03	Read Output Analogue Holding Registers	2000	read / writable
04	Read Input Analogue Input Registers	1000	read only
05	Write to Output Digital Status flags	4000	writable
06	Write to Output Analogue Holding Registers	2000	writable
43/14	Read Device ID	---	read only

7.5 REGISTER MAP

The Register Map specifies the details of storage locations (registers and flags) within the detectors.

Analogue Input Registers

(Input Registers are read only)

Function Code 04

REGISTER	DESCRIPTION	RANGE	M.U.
1000	Gas concentration level (% of full scale)	0...100	%
1001	Gas concentration level (parts per million)	0...65,535	ppm
1003	Sensor full scale	0...65,535	ppm
1004	Alarm Setpoint (% of full scale)	0...100	%
1005	Sensor timer	0...65,535	hours
1006	Modbus Address	1...247	---
1007	Software version	100	---

7.5.1 REGISTERS 1000 AND 1001: GAS CONCENTRATION LEVEL

The real time gas concentration is available in different formats:


- Register 1000 maintains the detected concentration in percentage (% of full scale).
- Register 1001 maintains the detected concentration in parts per million (ppm).

For example: a value of 33 represents, in register 1000, 33% of the maximum detectable gas concentration.



7.5.2 REGISTER 1003: SENSOR FULL SCALE (IN PPM)

The full scale sensor level is the maximum detectable gas concentration for the detector. This maximum rating is stored in register 1003, so, for the example register 1003, holds the value 1000 to represent 1000 parts per million (ppm).



7.5.3 REGISTER 1004: ALARM SETPOINT (% OF FULL SCALE)

The alarm setpoint is the threshold at which the gas concentration has reached a level to warrant the activation of the red LED alarm indication, the relay, the sounder and the Alarm flag by setting a 1 in register 3000.

The alarm setpoint can be controlled using the detector hardware by adjusting the potentiometer **P1** and monitoring the voltage on test point **TP1** with respect to test point **TP3** (0V).

Alternatively a software value can be written into register 2000 to set the alarm level in ppm and override the hardware potentiometer setting until the software value is reset back to zero, so although register 1004 is a read only register, its value can be modified by writing to register 2000.

The alarm setpoint register 1004 is measured as a percentage of the full scale so for example, 1.0 Volt measured between test points **TP1** and **TP3** corresponds to a 20% Alarm Setpoint given that the maximum voltage is 5.0 Volts.


The alarm setpoint register 1004 will contain 20 to represent 20% and this corresponds to a 200 ppm for a detector with a full scale range of 1000 ppm.


If a delay time is set in 2001 register (valued between 0 and 59 mins), when an alarm occurs:

- the red LED and the Alarm Flag will be immediately activated
- the relay and the sounder will be activated after the delay period is expired

After that the delay period is elapsed, the relay switches ON and the sounder din is audible.

NOTE: The duration of the delay is measured from the instant when the gas concentration reaches the alarm setpoint and the red LED and the alarm flag are activated.








7.5.4 REGISTER 1005: SENSOR TIMER

The sensor timer register keeps a count of the number of hours the sensor is on.

The register is incremented every hour and after one year the register will exceed 8760 hours and the Test Flag will be set to 1 to indicate that the detector requires testing.

The Test Flag Register is located at address 4001 and can be cleared to indicate that the sensor and detector have passed the annual test.



7.5.5 REGISTER 1006: MODBUS ADDRESS

The Modbus address is the value of address set by the hexadecimal switches.

7.5.6 REGISTER 1007: SOFTWARE VERSION

The software version is the revision of firmware operating on the processor of the detector.

Analogue Output Registers

(Output / Registers are readable & writable)

Function code 03 : read
Function code 06 : write

REGISTER	DESCRIPTION	RANGE	DETAILS
2000	Alarm setpoint (ppm)	0...65,535	alarm setpoint / threshold in parts per million
2001	Alarm delay	0...59	the Alarm Delay is the time in minutes after the gas concentration exceeds the alarm level and the Alarm Flag Register 300 is set to 1.
2002	Sounder mute duration	0...59	the Sounder Delay is the time in minutes the sounder is deactivated for during the alarm phase when the gas concentration exceeds the alarm set point.




7.5.7 REGISTER 2000: ALARM SETPOINT (IN PPM)

The alarm setpoint register 2000 stores the software setting for the alarm setpoint in parts per million (ppm). Writing the value zero into this register will enable the hardware potentiometer **P1** to determine the alarm setpoint.

If a value greater than zero and less than the full scale sensor limit in ppm is written into register 2000 then the hardware potentiometer setting is ignored and the value written into register 2000 determines the alarm setpoint.

For example, writing the value 500 into the alarm setpoint register 2000 effectively overrides the hardware alarm set point on the potentiometer **P1** and sets the alarm gas concentration threshold to 500 parts per million and will be displayed as 50 in register 1004 to represent 50% for a detector with a full scale range of 1000 ppm.





7.5.8 REGISTER 2001: ALARM DELAY

The Alarm Delay Register 2001 stores the software alarm delay period up to 59 minutes and the jumpers **J5** and **J6** set the hardware alarm delay period.


The alarm delay is the duration between the unit detecting a gas concentration above the alarm set point and the activation of the relay and the sounder.



Only modbus model: If jumpers **J5** and/or **J6** are present (ON) during the connection of modbus cable (on **CN4**), the software value is cleared following a restart whereby the power to the detector is turned off and then turned on again.

Following this restart the delay period is determined by hardware setting of jumpers J5 and J6.

If there are no jumpers on both **J5** and **J6** the delay period written into the alarm delay register 2001 is used as the delay and is memorised and reused after a power cycle when the power is turned off and back on.





7.5.11 REGISTER 2002: SOUNDER MUTE DURATION


The sounder mute duration is the time in minutes the sounder is deactivated for during the alarm phase (when the gas concentration has reached or exceeds the alarm setpoint).

The alarm condition will activate the red LED and set the alarm flag to the value 1.

The relay and the sounder will subsequently activate following any delay period and the alarm flag in register 3000.

The relay flag in register 3001 and the sounder flag in register 4000 will all be set to the value 1 to indicate the active alarm state.

Clearing the Sounder Flag, by writing the value zero into register 4000 will deactivate the sounder for the period defined by the sounder delay register 2002. The sounder delay is in minutes and the maximum value is 59 so for example if the value in register 2002 is **25**, then the sounder will be disabled for **25** minutes during an alarm condition. After this 25 minute mute period, the sounder will be reactivated if the detector is still detecting gas concentrations at or above the alarm setpoint, otherwise the sounder will not be reactivated if the gas concentration has fallen below the alarm setpoint.





Input Status Flags

(Input Status Flags are read only)

Function code 02

REGISTER	DESCRIPTION	RANGE	DETAILS
3000	Alarm	0/1	0: Gas concentration is less than the alarm setpoint. 1: Gas concentration is greater or equal to alarm setpoint
3001	Relay	0/1	0: Relay is not active. 1: Relay is active.
3002	Probe Error	0/1	0: Sensor present / in circuit and no open circuit fault detected. 1: Sensor absence or open circuit sensor fault is detected.
3003	Red LED	0/1	0: Red LED is OFF No alarm or fault condition exists. 1: Red LED is ON. Alarm Indication or Fault Indication if green LED is OFF.
3004	Green LED	0/1	0: Green LED is OFF. No power or fault condition if the red LED is ON. 1: Green LED is ON. Power indicator, detector powered ON.
3005	Sensor saturated	0/1	0: The gas level is between zero and the full-scale range. 1: The gas level is outside the bounds of zero and the unit full-scale.
3006	Sensor startup	0/1	0: The unit is operating normally. 1: The unit is starting up.

Output Status Flags

(Output Status Flags are readable & writable)

Function code 01 : read

Function code 05 : write

REGISTER	DESCRIPTION	RANGE	DETAILS
4000	Sounder flag	0/1	0: Sounder is OFF. 1: Sounder is ON.
4001	Sensor test required	0/1	0: Sensor does not require testing yet. 1: Sensor ON / operating for more than 1 year and requires testing.

Read Device ID

(Read-only)

Function code 43/14

This function code allows reading the identification and additional information relative to the physical and functional description of the device.

The implementation of this function follows the specification "MODBUS APPLICATION PROTOCOL SPECIFICATION V1.1b", section 6.21 as published by the Modbus Organisation.

The following Object IDs have been implemented:

OBJECT ID	NAME/DESCRIPTION	TYPE	VALUE	NOTES
0x00	VendorName	ASCII String	"INVENSYS"	
0x01	ProductCode	ASCII String	"00DE_0401" "00DF_0401"	Semiconductor version Infrared version
0x02	MajorMinorRevision	ASCII String	"0FA0_0001" "0FA1_0001"	Semiconductor version Infrared version

The following "Read Device ID code" options have been implemented:

01: request to get the basic device identification (stream access)

04: request to get one specific identification object (individual access)

8. WARNING



8.1 CONDITIONS OF USE

**Attention!: This product cannot be used in place of a SAFETY device.
It must be used only to signal an alarm.**

Sensors monitor a point as opposed to an area. If the gas leak does not reach the sensor then no alarm will be raised. Therefore, it is extremely important to carefully select the sensor location. Also consider ease of access for maintenance.

Things to do:

- Install the sensor inside the room at a proper height depending on the refrigerant. Being gases heavier than air, it is normally recommended to position **LKD** sensor lower than the average height of people inside the room.
- With heavier than air gases such as halocarbon and hydrocarbon refrigerants such as R404A, propane, and butane sensors should be located near ground level. With lighter than air gas e.g. ammonia, the sensor needs to be located above the equipment to be monitored on a bracket or high on a wall within 300 mm of. With similar density or miscible gases, such as CO₂, sensors should be mounted about head high - say 1.5m.
- install sensor away from draughts and heat sources.

Things not to do:

Do not mount **LKD** sensors:

- under reflective surfaces (e.g.: mirrors)
- inside electrical boards
- in or near bathrooms

8.2 LIABILITY AND RESIDUAL RISKS

Eliwell Controls srl, as a distributor of MURCO Ltd products, declines all liability for damage due to:

- installation/use other than expressly specified and, in particular, in conflict with the safety prescriptions set down in regulations and/or specified in this document
- tampering with and/or modification of the product
- installation/use on panels that do not comply with statutory laws and regulations

8.3 DISCLAIMER

This document is the exclusive property of **ELIWELL CONTROLS SRL** and may not be reproduced or circulated without the express permission of **ELIWELL CONTROLS SRL**. While all possible care has been taken to ensure the accuracy of this document, **ELIWELL CONTROLS SRL** cannot accept liability for any damage resulting from its use. The same applies to any person or company involved in preparing and editing this document.

ELIWELL CONTROLS SRL reserves the right to make aesthetic or functional changes at any time without notice.

MANUFACTURED BY: Murco Limited - 114a Georges Street Lower, Dun Laoghaire Co Dublin. IRELAND



Eliwell Controls Srl

Via dell' Industria, 15 Z. I. Paludi
32010 Pieve d' Alpago (BL) - Italy
Telephone +39 (0) 437 986 111
Facsimile +39 (0) 437 989 066

Sales:

+39 (0) 437 986 100 (Italy)
+39 (0) 437 986 200 (other countries)
saleseliwell@invensys.com

Technical Support:

Technical helpline: +39 (0) 437 986 300
email: techsuppeliwell@invensys.com

www.eliwell.com